


# AIR FORCE SPECIALTY CODE 4B051 BIOENVIRONMENTAL ENGINEERING

Occupational and Environmental  
Air/Gas Sampling



## QUALIFICATION TRAINING PACKAGE

**Accessibility:** *Publications and forms are available on the e-publishing website at <http://www.e-publishing.af.mil> for downloading or ordering.*

**Releasability:** *There are no releasability restrictions on this publication.*

## Table of Contents

<b>STS Line Item 4.5.2.4: Determine or establish air sampling strategies .....</b>	<b>1</b>
TRAINER GUIDANCE.....	1
TASK STEPS.....	2
TRAINEE REVIEW QUESTIONS .....	3
PERFORMANCE CHECKLIST.....	4
ANSWERS.....	5
<b>STS Line Item 4.5.2.5: Calculate sampling rates and volumes .....</b>	<b>6</b>
TRAINER GUIDANCE.....	6
TASK STEPS.....	7
TRAINEE REVIEW QUESTIONS .....	8
PERFORMANCE CHECKLIST.....	10
ANSWERS.....	11
<b>STS Line Item 4.5.2.6.1: Detector Tubes or Chips (Draeger Civil Defense Simultest Kit) .....</b>	<b>12</b>
TRAINER GUIDANCE.....	12
TASK STEPS.....	13
TRAINEE REVIEW QUESTIONS .....	15
PERFORMANCE CHECKLIST.....	16
ANSWERS.....	18
<b>STS Line Item 4.5.2.6.2: PID/FID .....</b>	<b>19</b>
TRAINER GUIDANCE.....	19
TASK STEPS.....	20
TRAINEE REVIEW QUESTIONS .....	23
PERFORMANCE CHECKLIST.....	24
ANSWERS.....	26
<b>STS Line Item 4.5.2.6.3: Portable GC/MS (HAPSITE®).....</b>	<b>27</b>
TRAINER GUIDANCE.....	27
TASK STEPS.....	28
PERFORMANCE CHECKLIST.....	33
<b>STS Line Item 4.5.2.6.4: Combustible Gas Meters: MSA Passport® Personal Alarm .....</b>	<b>37</b>
TRAINER GUIDANCE.....	37
TASK STEPS.....	38
PERFORMANCE CHECKLIST.....	39
<b>STS Line Item 4.5.2.6.4: Combustible Gas Meters: MSA Sirius® Multigas Detector.....</b>	<b>40</b>
TRAINER GUIDANCE.....	40
TASK STEPS.....	41
PERFORMANCE CHECKLIST.....	47

<b>STS Line Item 4.5.2.7: Calibrate / Operate air sampling pumps (Low/High flow pump)</b>	50
TRAINER GUIDANCE	50
TASK STEPS	51
TRAINEE REVIEW QUESTIONS	52
PERFORMANCE CHECKLIST	53
ANSWERS	54
<b>STS Line Item 4.5.2.8: Collect area air samples</b>	55
TRAINER GUIDANCE	55
TASK STEPS	56
TRAINEE REVIEW QUESTIONS	57
PERFORMANCE CHECKLIST	58
ANSWERS	59
<b>STS Line Item 4.5.2.9: Collect breathing zone air samples</b>	60
TRAINER GUIDANCE	60
TASK STEPS	61
TRAINEE REVIEW QUESTIONS	62
PERFORMANCE CHECKLIST	63
ANSWERS	65
<b>STS Line Item 4.5.2.10: Calculate equivalent OEELs</b>	66
TRAINER GUIDANCE	66
TASK STEPS	67
TRAINEE REVIEW QUESTIONS	68
PERFORMANCE CHECKLIST	69
ANSWERS	70
<b>STS Line Item 4.5.2.11: Convert raw concentrations (i.e., grams to mg/m<sup>3</sup>)</b>	71
TRAINER GUIDANCE	71
TASK STEPS	72
TRAINEE REVIEW QUESTIONS	73
PERFORMANCE CHECKLIST	75
ANSWERS	76
<b>STS Line Item 4.5.2.12: Calculate time-weighted averages</b>	78
TRAINER GUIDANCE	78
TASK STEPS	79
TRAINEE REVIEW QUESTIONS	80
PERFORMANCE CHECKLIST	82
ANSWERS	83
<b>STS Line Item 4.5.2.13: Calculate upper and lower confidence limits</b>	85
TRAINER GUIDANCE	85
TASK STEPS	86
TRAINEE REVIEW QUESTIONS	87

PERFORMANCE CHECKLIST.....	88
ANSWERS.....	89
<b>STS Line Item 4.5.2.14: Calculate compliance factors (unity).....</b>	<b>90</b>
TRAINER GUIDANCE.....	90
TASK STEPS.....	91
TRAINEE REVIEW QUESTIONS .....	92
PERFORMANCE CHECKLIST.....	94
ANSWERS.....	95
<b>STS Line Item 4.5.2.16: Interpret air sample results.....</b>	<b>97</b>
TRAINER GUIDANCE.....	97
TASK STEPS.....	98
TRAINEE REVIEW QUESTIONS .....	99
PERFORMANCE CHECKLIST.....	100
ANSWERS.....	101
<b>STS Line Item 4.5.2.17: DOEHRS data entry.....</b>	<b>102</b>
TRAINER GUIDANCE.....	102
TASK STEPS.....	103
TRAINEE REVIEW QUESTIONS .....	104
PERFORMANCE CHECKLIST.....	105
ANSWERS.....	106

### STS Line Item 4.5.2.4: Determine or establish air sampling strategies\*

#### TRAINER GUIDANCE

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	Completion of TRAINING MODULE (4.2.2) Perform Routine Assessments.**
<b>Training References:</b>	<ul style="list-style-type: none"> <li>• <i>Fundamentals of Industrial Hygiene</i>, 5th Ed, Chapter 15.</li> <li>• CDC lesson cited below.</li> </ul>
<b>Additional Supporting References:</b>	<ul style="list-style-type: none"> <li>• American Conference of Governmental Industrial Hygienist (ACGIH), <i>TLVs® and BEIs®</i> (guidebook), most current edition.</li> <li>• 29 CFR 1910.10xx, <a href="http://www.osha.gov/Publications/osh3122.pdf">www.osha.gov/Publications/osh3122.pdf</a> ***</li> <li>• NIOSH <i>Manual of Analytical Methods</i>, most current edition.</li> <li>• NIOSH Publication No.77-173, <i>Occupational Exposure Sampling Strategy Manual</i>, Chapter 3.</li> <li>• <i>The Occupational Environment: Its Evaluation, Control, and Management</i>, 2nd Ed, Chapter 10.</li> <li>• OSHA <i>Chemical Sampling Information (CSI)</i>.</li> </ul>
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>• Activity assessment data for specified work area.</li> <li>• American Conference of Governmental Industrial Hygienist (ACGIH), <i>TLVs® and BEIs®</i> (guidebook), most current edition.</li> <li>• NIOSH <i>Manual of Analytical Methods</i>, most current edition.</li> <li>• Computer access.</li> <li>• Calculator.</li> </ul>
<b>Specific Techniques:</b>	Conduct hands-on training and evaluation.
<b>Criterion Objective:</b>	Given activity assessment data and listed references, determine or establish an air sampling strategy successfully completing all checklist items with limited assistance on only the hardest parts.
<p><b>Notes:</b></p> <p>*For this QTP the assumption has been made that if an air sampling strategy is needed then there is a need for further (specialized) assessment, thus a less than desirable level of confidence in hazard characterization exists. To identify a course of action (strategy), you must first identify the gap in data that is causing the lack of confidence. A good sampling strategy makes use of both worst-case and typical sampling methods, each selected to answer the questions what, where, when, how, and whom to sample.</p> <p>**Hazard characterization task steps are outlined in TRAINING MODULE (4.2.2), which is listed as a prerequisite to this QTP. Successful completion of TRAINING MODULE (4.2.2) helps to ensure the trainee is better suited to comprehend and relate the rationale for developing air sampling strategies.</p> <p>***29 CFR 1910.10xx refers to all sections of 1910 which address toxic and hazardous substances, e.g., 1910.1017 discusses vinyl chloride.</p>	

## TASK STEPS

1. Identify the project hazard of concern and gather details<sup>1</sup>.
2. Determine goal for sampling (detailed analysis vs. screening).
3. Define the population at risk.
4. Select employee(s) to be sampled considering observations, established goal/purpose for sampling and data gap<sup>2</sup>.
5. Research contaminants of concern gathering information such as regulatory requirements, chemical characteristics, occupational exposure limit (OEL), and sampling methodology, etc.
6. Select measurement type (i.e., full period, partial period, etc)<sup>3</sup>.
7. Identify/consider occupational exposure variations (day to day, shift to shift, seasonal, etc).
8. Identify/consider accuracy of sampling and analytical methods.
9. Identify/consider number of samples needed to attain the required accuracy of the exposure measurement.
10. Select measurement location.
11. Select shift to be sampled.
12. Select collection method.
13. Determine sampling rates and volumes.<sup>4</sup>
14. Determine sample frequency.<sup>5</sup>
15. Utilize DOEHRs or equivalent.

### LOCAL REQUIREMENTS:

### NOTES:

1. Observe activity; review existing activity assessment data and determine confidence in hazard characterization; and identify why confidence is less than desirable (data gap--what information is missing).
2. Select the maximum risk employee for each work operation based on proximity and length of exposure to the hazardous substance -or- Identify random individuals in each homogeneous work group where a max risk employee cannot be identified. When using the random individual approach, tables 3.1 and 3.2 in NIOSH Publication No. 77-173, or other random number selection process can be used to determine the required number of employees.
3. When selecting the measure type, you will need to consider regulatory requirements, expected contaminant concentrations, and the applicable OEL type (8-hour TWA vs. 15-minute short-term exposure limit [STEL]).
4. It is up to you to decide rates and volumes that are within the recommended ranges based on such things as the goal for sampling, how much time you have to sample, and the concentration of contaminant you expect to encounter in the area of concern. You can calculate how long you must collect a sample using the following formula:

$$\text{Volume}_{\text{liters}} = \text{flowrate}_{\text{lpm}} \times \text{time}_{\text{min}} \text{ which can be restated to solve for how long you must collect a sample as}$$

$$\text{Time}_{\text{min}} = \frac{\text{Volume}_{\text{liters}}}{\text{Flowrate}_{\text{lpm}}}$$

5. Sampling frequency is based on the following:
  - Regulatory requirements.
  - Characterization needs.
  - Substances exceeding the standard.

**TRAINEE REVIEW QUESTIONS**

---

**STS Line Item 4.5.2.4: Determine or establish air sampling strategies**

---

- |   |
|---|
| 1. List factors that must be considered for formulating a sampling strategy.          |
| 2. List considerations for determining the maximum risk worker.                       |
| 3. The volume of air to be sampled and duration of sampling is based on what factors? |
| 4. List the considerations for determining the number of samples to take.             |

## PERFORMANCE CHECKLIST

### STS Line Item 4.5.2.4: Determine or establish air sampling strategies

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...		YES	NO
1. Identify the project hazard of concern and gather details?			
2. Determine goal for sampling (detailed analysis vs. screening)?			
3. Define the population at risk?			
4. Select employee(s) to be sampled considering observations, established goal/purpose for sampling and data gap?			
5. Research contaminants of concern gathering information such as regulatory requirements, chemical characteristics, OEL, and sampling methodology, etc?			
6. Select measurement type (i.e., full period, partial period, etc)?			
7. Identify/consider occupational exposure variations (day to day, shift to shift, seasonal, etc)?			
8. Identify/consider accuracy of sampling and analytical methods?			
9. Identify/consider number of samples needed to attain the required accuracy of the exposure measurement?			
10. Select measurement location?			
11. Select shift to be sampled?			
12. Select collection method?			
13. Determine sampling rates and volumes?			
14. Determine sample frequency?			
15. Utilize DOEHRS or equivalent?			
<b>Did the trainee successfully complete the task?</b>			

---

 TRAINEE NAME (PRINT)

---

 TRAINER NAME (PRINT)



## ANSWERS

1. List factors that must be considered for formulating a sampling strategy.

A: Observe activity; review existing activity assessment data and determine confidence in hazard characterization; and identify why confidence is less than desirable (data gap--what information is missing).

(Source: *Fundamentals of Industrial Hygiene*, 5th Ed, Chapter 15 and Career Development Course 4B051)

2. List considerations for determining the maximum risk worker.

A: Select the maximum risk employee for each work operation based on proximity and length of exposure to the hazardous substance -or- Identify random individuals in each homogeneous work group where a max risk employee cannot be identified. When using the random individual approach, tables 3.1 and 3.2 in NIOSH Publication No. 77-173, or other random number selection process can be used to determine the required number of employees.

(Source: *Fundamentals of Industrial Hygiene*, 5th Ed, Chapter 15

NIOSH Publication No.77-173, *Occupational Exposure Sampling Strategy Manual*, Chap. 3)

3. The volume of air to be sampled and duration of sampling is based on what factors?

A: When selecting the measure type, you will need to consider regulatory requirements, expected contaminant concentrations, and the applicable OEEL type (8-hour TWA vs. 15-minute short-term exposure limit [STEL]).

(Source: *Fundamentals of Industrial Hygiene*, 5th Ed, Chapter 15 and Career Development Course 4B051)

4. List the considerations for determining the number of samples to take.

A: It's up to you to decide rates and volumes that are within the recommended ranges based on such things as the goal for sampling, how much time you have to sample, and the concentration of contaminant you expect to encounter in the area of concern. You can calculate how long you must collect a sample using the following formula:

$$\text{Time}_{\min} = \frac{\text{Volume}_{\text{liters}}}{\text{Flowrate}_{\text{lpm}}}$$

(Source: *Fundamentals of Industrial Hygiene*, 5th Ed, Chapter 15 and Career Development Course 4B051)

---

**STS Line Item 4.5.2.5: Calculate sampling rates and volumes**


---

**TRAINER GUIDANCE**

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	None
<b>Training References:</b>	<ul style="list-style-type: none"> <li>• Fundamentals of Industrial Hygiene, 5th Ed, Chapters 15 &amp; 16.</li> <li>• The Occupational Environment: Its Evaluation, Control, and Management, 2nd Ed, Chapter 10.</li> </ul>
<b>Additional Supporting References:</b>	<ul style="list-style-type: none"> <li>• 29 CFR 1910.10XX</li> <li>• NIOSH Pub 77-173, Occupational Exposure Sampling Strategy Manual, Chapter 3.</li> <li>• OSHA Chemical Sampling Information (CSI).</li> </ul>
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>• List of chemical substances to research.</li> <li>• Calculator.</li> <li>• USAFSAM Automated Sampling Guide.</li> <li>• NIOSH Manual of Analytical Methods (NMAM).</li> </ul>
<b>Specific Techniques:</b>	Conduct hands-on training and evaluation.
<b>Criterion Objective:</b>	Given a list of substances, calculator, and references, calculate sampling rates and volumes successfully completing all checklist items with no trainer assistance.
<b>Notes:</b>	

**TASK STEPS**

- |  |
|--|
| 1. Calculate sampling flow rate (FR). <sup>1</sup><br>2. Calculate sampling volume (V). <sup>1</sup> |
|--|

**LOCAL REQUIREMENTS: N/A****NOTES:**

1. Determine recommended sampling volume (V).  
Determine sampling time (T).

Substitute V and T values in the equation and solve.

This formula can be manipulated to determine each individual variable.

$$Volume = Flow Rate \times Time$$

OR

$$Flow Rate = \frac{Volume}{Time}$$

OR

$$Time = \frac{Volume}{Flow rate}$$

**TRAINEE REVIEW QUESTIONS**

---

**STS Line Item 4.5.2.5: Calculate sampling rates and volumes**

---

1. If you have a recommended sample volume of 0.25 L and an operation that is lasting 20 minutes, what is your flow rate?

2. What flow rate would you use to collect a total sample volume of 3 L in 60 minutes?

3. If you have a recommended sample flow rate of 0.2 L/min for an operation that is lasting 40 minutes, what is your sample volume?

4. What sample volume would you have if the recommended flow rate was 0.03 L/min and your sample time is 1.5 hours?

5. What sample volume would you have if the recommended flow rate was 2.0 L/min and your sample time is 2.5 hours?

**PERFORMANCE CHECKLIST****STS Line Item 4.5.2.5: Calculate sampling rates and volumes**

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...		YES	NO
1. Calculate sampling flow rate (FR)?			
2. Calculate sampling volume (V)?			
<b>Did the trainee successfully complete the task?</b>			

\_\_\_\_\_  
TRAINEE NAME (PRINT)\_\_\_\_\_  
TRAINER NAME (PRINT)

**ANSWERS**

1. If you have a recommended sample volume of 0.25 L and an operation that is lasting 20 minutes, what is your flow rate?

A:

$$0.25\text{L} / 20 \text{ mins} = 0.0125 \text{ L/min}$$

(Source: Step #1 of this QTP)

2. What flow rate would you use to collect a total sample volume of 3 L in 60 minutes?

A:

$$3\text{L} / 60 \text{ mins} = 0.05 \text{ L/min}$$

(Source: Step #1 of this QTP)

3. If you have a recommended sample flow rate of 0.2 L/min for an operation that is lasting 40 minutes, what is your sample volume?

A:

$$0.2 \text{ L/min} \times 40 \text{ mins} = 8\text{L}$$

(Source: Step #2 of this QTP)

4. What sample volume would you have if the recommended flow rate was 0.03 L/min and your sample time is 1.5 hours?

A:

$$1.5 \text{ hours} = 90 \text{ mins}$$

$$0.03 \text{ L/min} \times 90 \text{ mins} = 2.7 \text{ L}$$

(Source: Step #2 of this QTP)

5. What sample volume would you have if the recommended flow rate was 2.0 L/min and your sample time is 2.5 hours?

A:

$$2.5 \text{ hours} = 150 \text{ mins}$$

$$2.0 \text{ L/min} \times 150 \text{ mins} = 300\text{L}$$

(Source: Step #2 of this QTP)

---

### STS Line Item 4.5.2.6.1: Detector Tubes or Chips (Draeger Civil Defense Simultest Kit)\*

---

#### TRAINER GUIDANCE

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	Draeger Civil Defense Simultest Kit (CDS) Web-based Training.
<b>Training References:</b>	<ul style="list-style-type: none"> <li>• Equipment User's Manual.</li> <li>• <i>The Occupational Environment: Its Evaluation, Control, and Management</i> / pp 295-297</li> </ul>
<b>Additional Supporting References:</b>	None
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>• User's manual.</li> <li>• CDS kit.</li> </ul>
<b>Specific Techniques:</b>	Conducts hands-on training and evaluation of operation of equipment with verification of steps.
<b>Criterion Objective:</b>	Given a CDS kit, demonstrate how to prepare and perform the Set I (for S-Mustard, Phosgene, Hydrogen Cyanide, Lewisite, and N-Mustard) and Set V (for Nerve Agents, Phosgene, Cyanogen Chloride, Chlorine, and S-Mustard) Simultest sets successfully completing all checklist items with no trainer assistance.
<b>Notes:</b> *The CDS kit has two different 5-tube Simultest sets (Sets I and V) that can identify various nerve, blood, lung, nose and throat irritating agents. Each test takes less than five minutes to complete and does not require warm-up time or calibration.	



## TASK STEPS

### **PUMP LEAK TEST:**

1. Insert an unopened detector tube into the pump socket.
2. Squeeze the pump completely and release.
3. After 15 minutes, look for the end-of-stroke indicator.<sup>1</sup>
4. If the pump is deemed leak-proof, remove the tube and reset the counter on the pump to zero.

### **PREPARE AND OPERATE ACCURO® PUMP WITH DETECTOR TUBES:**

1. Determine which set tubes will be used for sampling.<sup>2</sup>
2. Open detector tubes only on pump side first (direction of arrow).<sup>3</sup>
3. Insert the open ends of the tube(s) into the tube adapter (flow arrows pointing in).
4. Score and break off tips on other side of set.
5. Activate the cyanogen chloride tube (Simultest Set V only).<sup>4</sup>
6. Connect the tube set to pump.<sup>5</sup>
7. Check stroke number.<sup>6</sup>
8. Operate the pump.<sup>7</sup>
9. Complete sampling.<sup>8</sup>
10. Remove the used tubes from the adapter and dispose of them correctly.<sup>9</sup>
11. Purge pump.<sup>10</sup>

### **RECORD DATA:**

1. Utilize DOEHS or equivalent as applicable.

### **LOCAL REQUIREMENTS: N/A**

### **NOTES:**

1. If the end-of-stroke indicator does not appear, the pump is leak-proof and you are ready to continue. If the end-of-stroke indicator appears, your pump is not leak-proof and therefore should not be used.
2. Some tubes contain ampoules that require additional steps, in these circumstances, refer to laminated card for specific instructions. The laminated instruction cards provide a quick reference for easy use and color change interpretations specific to each ampoule (detector tube). The laminated instruction cards also provide reference for groups of related contaminants.
3. Tube Opener Procedures:
  - A. Simultest Tube Opener:
    - Carefully scrape the ceramic edge of the tube set opener against the ends of the tubes (at an angle) multiple times to score all five glass tips.
    - With the ceramic cutter UP, push opener completely over rubber tube block and apply pressure down until all tube tips break off (if some tubes don't break off, re-scrape or use the single-tube breaker, described below).

B. Deluxe Tube Opener (for individual tubes):

- Insert the tube into the cutter. Keep it pressed against the ceramic edge while turning it (scoring it).
- To open the tube, insert the tube into the opener and push on it at an angle until the tip breaks off (dispose of glass tip).

C. Pump Tube Opener (for individual tubes):

- To score and open an individual tube using the opener on the Accuro® pump; insert the tube into the opener. Press the tube against the ceramic edge while turning it to score the glass; then pull the tube at an angle until the tip breaks off (dispose of glass tip).
- When using the pump to open a tube, be sure to keep the pump facing downwards to prevent any glass splinters from entering the pump.

4. Before beginning the test using the Simultest Set V detector tubes, you will need to activate the cyanogen chloride tube. Remove the tube from the holder and bend the tube between the two black dots, allowing the reagent to flow onto the indicator until it is moistened. Place the tube back into the test holder, always keeping the arrows on the tube pointing towards the pump.

5. A special adapter is used to connect the Simultest Set to the pump. This adapter consists of a 5-slot manifold for the tube sets, 1 meter extension hose that connects to the Accuro® pump.

6. The number of strokes required is stated on the back of the Simultest Set holder and is also included in the Instructions for Use. Conveniently, both Simultest Set I and V require 50 strokes.

7. Grip and hold the Accuro® pump so that the end-of-stroke indicator and stroke counter are facing you. Squeeze the pump until it is fully compressed (the stroke indicator will advance) then release to allow the bellows to re-expand by itself until. A white dot reappears on the top of the pump and indicates re-expansion is complete (end of stroke).

8. Repeat STEP 6 until the number on the stroke counter corresponds to the number of required strokes.

9. All tubes, even those with negative results, cannot be reused and must be disposed of as hazardous waste.

10. The Accuro® pump must be purged after every use, regardless of test results. Flush out the pump by performing a few pump strokes (STEP 6) in clean air.

## TRAINEE REVIEW QUESTIONS

---

### STS Line Item 4.5.2.6.1: Detector Tubes or Chips (Draeger Civil Defense Simultest Kit)

---

1. When sampling using the Simultest Set V, what step must be performed prior to beginning the test?

**PERFORMANCE CHECKLIST****STS Line Item 4.5.2.6.1: Detector Tubes or Chips (Draeger Civil Defense Simultest Kit)**

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...		YES	NO
<b>PUMP LEAK TEST</b>			
1. Insert an unopened detector tube into the pump socket?			
2. Squeeze the pump completely and release?			
3. After 15 minutes, look for the end-of-stroke indicator.?			
4. If the pump is deemed leak-proof, remove the tube and reset the counter on the pump to zero?			
<b>PREPARE AND OPERATE ACCURO® PUMP WITH DETECTOR TUBES</b>			
1. Determine which set tubes will be used for sampling?			
2. Open detector tubes only on pump side first (direction of arrow)?			
3. Insert the open ends of the tube(s) into the tube adapter (flow arrows pointing in)?			
4. Score and break off tips on other side of set?			
5. Activate the cyanogen chloride tube (Simultest Set V only)?			
6. Connect the tube set to pump?			
7. Check stroke number?			
8. Operate the pump?			
9. Complete sampling?			
10. Remove the used tubes from the adapter and dispose of them correctly?			
11. Purge pump?			

<b>RECORD DATA</b>			
1. Utilize DOEHS or equivalent as applicable?			
<b>Did the trainee successfully complete the task?</b>			

---

TRAINEE NAME (PRINT)

---

TRAINER NAME (PRINT)

**ANSWERS**

1. When sampling using the Simultest Set V, what step must be performed prior to beginning the test?

A: Before beginning the test using the Simultest Set V detector tubes, you will need to activate the cyanogen chloride tube. Remove the tube from the holder and bend the tube between the two black dots, allowing the reagent to flow onto the indicator until it is moistened. Place the tube back into the test holder, always keeping the arrows on the tube pointing towards the pump

(Source: Equipment User's Manual)

---

**STS Line Item 4.5.2.6.2: PID/FID**


---

**TRAINER GUIDANCE**

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	None
<b>Training References:</b>	<ul style="list-style-type: none"> <li>• TVA-1000B Toxic Vapor Analyzer Instruction Manual</li> <li>• TVA-1000B Operational Checklist (ESOH Service Center Website)</li> <li>• Bioenvironmental Engineer's Guide to TVA-1000B (ESOH Service Center Website)</li> </ul>
<b>Additional Supporting References:</b>	None
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>• TVA-1000B Toxic Vapor Analyzer Instruction Manual</li> <li>• TVA 1000B</li> <li>• Calibration gases (isobutylene, methane, zero grade air)</li> <li>• Tedlar bag</li> </ul>
<b>Specific Techniques:</b>	Conduct hands-on training and evaluation of calibration and operation of equipment with verification of steps.
<b>Criterion Objective:</b>	Given a TVA 1000B, perform calibration and functional check on the analyzer, demonstrating how to operate the analyzer successfully completing all the checklist items with limited no trainer assistance.
<b>Notes:</b> * The TVA-1000B Toxic Vapor Analyzer is a direct reading portable monitor that can display, monitor, and log data in either a flame ionization detector (FID), a photo ionization detector (PID), or both simultaneously to provide real-time measurements of organic, and some inorganic, vapor concentrations in air. It cannot confidently determine unknowns at low ppm (parts per million). Therefore, in these types of situations it is recommended that the analyzer be used more for approximations when exact concentrations are not required.	

**TASK STEPS****BEFORE STARTING THE UNIT, PERFORM THE FOLLOWING STEPS:\***

1. Charge battery.
2. Connect sample probe.<sup>1</sup>
3. Fill/install hydrogen tank (FID versions).<sup>2</sup>
4. Open the hydrogen valve (FID versions).

**TO USE THE UNIT, EXECUTE THE FOLLOWING START AND CALIBRATION PROCEDURE: <sup>3</sup>**

1. Press ON.
2. Press CONTROL.
3. Press 3 to ignite.
4. Press 2 = setup.
5. Press 1 = calibrate
6. Press 2 = span concentration.
7. Enter span concentration for calibration gas being used.<sup>4</sup>
8. Press 3 = zero.
9. Press 1 = both.
10. Challenge analyzer with zero gas sample.
11. Press ENTER = start.
12. Wait to stabilize.
13. Press ENTER = start (write down zero counts)
14. Press 4 = span
15. Press 2 = PID.
16. Press ENTER = start.
17. Challenge analyzer with isobutylene span gas and wait for readings to stabilize.
18. Press ENTER to accept (write down span counts for PID)
19. Press 4 = span.
20. Press 3 = FID.
21. Press ENTER = start.
22. Challenge analyzer with methane span gas and wait for readings to stabilize.
23. Press ENTER = accept (write down span counts for FID)
24. Press 5 = response factor.
25. Confirm that response factor says "RF0:DEFAULT"
26. Verify zero count is within the correct range. (PID, 10.6eV 2000-8000/11.8eV 2000-20,000) (FID <5000)
27. Verify the detector sensitivity is within range. (PID, 10.6eV 3500-6000 ppm, 11.8eV 300-900 ppm) (FID 160-260 ppm)
28. Press EXIT two times to main menu.
29. Press 1 = run.
30. Take background reading.
31. Conduct monitoring.
32. Record data.
33. Power down unit.<sup>5</sup>
34. Remove the hydrogen gas tank from the side of the instrument (if using FID).
35. Utilize DOEHS or equivalent as applicable.



**LOCAL REQUIREMENTS:****NOTES:**

1. The sample probe assembly is a hand-held device that enables you to take vapor samples at precise locations. It connects to the instrument by means of an umbilical. The umbilical has two quick-disconnect fasteners (one electrical, one sample line) at the instrument end.
2. The FID mode is used to detect most organic compounds and can be used to detect gaseous hydrocarbons in depressions or confined spaces. It is best suited to detect combustible compounds such as gasoline and methane. The PID mode is sensitive to compounds with double bonds, such as aromatic and chlorinated compounds. It can also measure some inorganic compounds that the FID does not detect, such as ammonia, carbon disulfide, carbon tetrachloride, chloroform, ethylamine, formaldehyde, and hydrogen sulfide. Calibration must be completed each day the TVA-1000B is used. The FID is calibrated with methane and the PID is calibrated with isobutylene.

To refill the hydrogen tank, follow these steps:

1. Turn the supply tank valve to OFF.
  2. Attach the tank filler adapter to the supply cylinder with valve and manifold valves in OFF position.
  3. Attach the TVA-1000B hydrogen tank to the tank filler adapter (left hand thread-do not over tighten).
  4. Open the supply tank valve.
  5. Move the fill adapter valve to FILL position.
  6. Wait for TVA-1000B tank to fill (may take two to three minutes because of flow restrictors in the tank and fill adapter). Do not fill past 2200psi.
  7. Once full, close the fill adapter valve.
  8. Remove the TVA-1000B tank.
  9. Close the supply cylinder valve.
  10. Reopen the adapter valve to release gas remaining in tank fill adapter (removes pressure and makes adapter removal easier).
  11. Remove the tank fill adapter. (Always remove tank from instrument for storage.)
3. Calibration must be completed each day the TVA-1000B is used. Prior to performing calibration, the instrument must be on and warmed up for approximately 30 minutes. The pump must be ON, the PID lamp must be ON, and the FID must be ignited throughout the warm-up period.
  4. If PID only, enter concentration of isobutylene. If FID only, enter concentration of methane. If dual, enter concentration of both gases.
  5. To power down this instrument, press and hold the OFF key. With FID versions, you must also shut off the gas valve to avoid depleting the tank supply.



TVA-1000B

**\*Key Functions:**

*ON:* The ON key enables power from the battery to the instrument.

*OFF:* The OFF key disables power from the battery to the instrument.

*CONTROL:* The CONTROL key is multi-function and is used to turn the pump, PID, and FID: on or off, and to ignite the FID.

*EXIT:* The EXIT key clears any entry made in error or bypasses information that you do not want to change, and clears error or warning screens.

*ENTER:* The ENTER key has three functions:

- Press ENTER if you have typed one or more characters and wish to
- Keep that information.
- Press ENTER to respond to a menu question.
- Press ENTER instead of the LOG key on the standard probe to initiate logging.

*Left/Right Arrows:* The left and right arrow keys move character entry positions.

*Up/Down Arrows:* The up and down arrow keys make page selections or scroll through options in SETUP entry screens.

*Alphanumeric:* The alphanumeric keys enable you to type letters or numbers into various menus. If a display asks for a number only, simply press the desired key. Two steps are required to type an alphanumeric character. First, press the key with the desired letter or number. The screen then displays a selection prompt at the bottom in which 1 = first letter, 2 = second letter, 3 = third letter, and 0 = number. Press the appropriate key to execute the selection. Three uses:

- Select menu options
- Enter numbers, 0-9, using single keystroke
- Enter alphanumeric data, A-Z, 0-9, SPACE, using 2 keystrokes per character

**TRAINEE REVIEW QUESTIONS**

---

**STS Line Item 4.5.2.6.2: PID/FID**

---

- |  |
|--|
| 1. Which detector(s) within the TVA-1000B is/are able to distinguish inorganic material?           |
| 2. How should the TVA-1000B be decontaminated?   |
| 3. How does the ion potential (IP) directly relate to the detection capabilities of the TVA-1000B? |
| 4. How is the response factor calculated?  |

## PERFORMANCE CHECKLIST

### STS Line Item 4.5.2.6.2: PID/FID

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...		YES	NO
<b><i>BEFORE STARTING THE UNIT</i></b>			
1. Charge battery?			
2. Connect sample probe?			
3. Fill/install hydrogen tank (FID versions)?			
4. Open the hydrogen valve (FID versions)?			
<b><i>TO USE THE UNIT, EXECUTE THE FOLLOWING START AND CONFIGURE PROCEDURE</i></b>			
1. Press ON?			
2. Press CONTROL?			
3. Press 3 to ignite?			
4. Press 2 = setup?			
5. Press 1 = calibrate?			
6. Press 2 = span concentration?			
7. Enter Span Concentration for calibration gas being used?			
8. Press 3 = zero?			
9. Press 1 = both?			
10. Challenge analyzer with zero gas sample?			
11. Press ENTER = start?			
12. Wait to stabilize?			
13. Press ENTER = start?			

14. Press 4 = span?			
15. Press 2 = PID?			
16. Press ENTER = start?			
17. Challenge analyzer with isobutylene span gas and wait for readings to stabilize?			
18. Press ENTER to accept?			
19. Press 4 = Span?			
20. Press 3 = FID?			
21. Press ENTER = start?			
22. Challenge analyzer with methane span gas and wait for readings to stabilize?			
23. Press ENTER = accept?			
24. Press 5 = response factor?			
25. Confirm that response factor says "RF0:DEFAULT"?			
26. Verify zero count is within the correct range. (PID, 10.6eV 2000-8000/11.8eV 2000-20,000) (FID <5000)			
27. Verify the detector sensitivity is within range. (PID, 10.6eV 3500-6000 ppm, 11.8eV 300-900 ppm) (FID 160-260 ppm)			
28. Press EXIT two times to main menu?			
29. Press 1 = run?			
30. Take background reading?			
31. Conduct monitoring?			
32. Record data?			
33. Power down unit?			
34. Remove the hydrogen tank from the side of the instrument (if using FID)?			
35. Utilize DOEHRS or equivalent as applicable?			
<b>Did the trainee successfully complete the task?</b>			

---

 TRAINEE NAME (PRINT)

---

 TRAINER NAME (PRINT)

**ANSWERS**

1. Which detector(s) within the TVA-1000B is/are able to distinguish inorganic material?

A: Photoionization Detector

(Source: Bioenvironmental Engineer's Guide to TVA-1000B)

2. How should the TVA-1000B be decontaminated?

A: The TVA-1000B can be decontaminated by wiping the exterior with a moist towel. Do NOT decontaminate the TVA-1000B by submerging it in water. If the TVA-1000B is accidentally contaminated by drawing a liquid sample into the probe head, it is recommended to call the manufacturer, Thermo Fisher Scientific.

(Source: Bioenvironmental Engineer's Guide to TVA-1000B)

3. How does the ion potential (IP) directly relate to the detection capabilities of the TVA-1000B?

A: Dependent upon what lamp (10.6 eV or 11.8 eV) is installed for the PID will correlate to the detection of the chemical in question. For example, acetaldehyde has an IP of 10.21 therefore it can be detected by either a 10.6 eV or an 11.8 eV PID lamp but chlorine has an IP of 11.47 so it cannot be detected by the 10.6 eV. An 11.8eV lamp would have to be used.

(Source: Bioenvironmental Engineer's Guide to TVA-1000B)

4. How is the response factor calculated?

Response Factor = Actual Concentration / Measured Concentration

(Source: Bioenvironmental Engineer's Guide to TVA-1000B)

---

**STS Line Item 4.5.2.6.3: Portable GC/MS (HAPSITE®)\***


---

**TRAINER GUIDANCE**

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	Complete Computer Based Training.
<b>Training References:</b>	<ul style="list-style-type: none"> <li>• Inficon Equipment User's Manual.</li> <li>• <i>HAPSITE® Smart Plus Chemical Identification System Operating Manual (ESOH Service Center Website)</i></li> </ul>
<b>Additional Supporting References:</b>	<ul style="list-style-type: none"> <li>• <i>Fundamentals of Industrial Hygiene</i>, 5<sup>th</sup> Edition, Chapter 17.</li> <li>• <i>Technical Report on BE HAPSITE® Preventive Maintenance and KD Analytical Support Guidance</i>, July 21, 2010</li> <li>• <i>HAPSITE® GC/MS Training Guide – United States Training Version</i>, 2002</li> </ul>
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	HAPSITE® (GC/MS) VOC test sample
<b>Specific Techniques:</b>	Conduct hands-on training and evaluation.
<b>Criterion Objective:</b>	Given a HAPSITE® (GC/MS), perform pre-operational check and operate instrument successfully completing all checklist items with NO trainer assistance.

**Notes:**

\*The HAPSITE® is a gas chromatograph/mass spectrometer (GC/MS) proven to provide verifiable data for critical health-risk decisions. The HAPSITE® systems deliver fast, dependable on-site analysis of volatile organic compounds (VOCs) in air, water, and soil for emergency response, environmental, hazardous waste, industrial hygiene, process monitoring, and medical applications. The HAPSITE® Headspace sampling system supports the HAPSITE® Smart Chemical Identification System in detecting and identifying VOCs in water or soil on-site or from another location.

INFICON recommends storing the HAPSITE® Smart in extended standby mode. This keeps the NEG (pump) operating at 400°C and the ion pump ON to maintain proper vacuum conditions. Extended standby ensures the battery is charged and ready for deployment/response. While extended standby is recommended, it is not a substitute for system use and it is not a feature to extend the time period between system operations. Using the system or running a weekly Blank Run is the best method to ensure overall operational readiness.

The Guidance Document (HAPSITE® Field Guide) referenced above is designed to provide user's the capability to maximize the use of deployment technology at both garrison and deployed environments in both routine and emergency response situations.

## TASK STEPS

### START UP FROM STANDBY MODE:

(These steps are *ONLY* for resuming use when the HAPSITE® has been placed in STANDBY MODE.)

1. Using your thumbs, Open front panel of HAPSITE®.<sup>1</sup>
2. Insert purple-banded Nitrogen gas canister into the opening with the purple stripe.<sup>2</sup>
3. Insert yellow-banded Internal Standard gas canister into bottom canister opening marked with yellow stripe.<sup>2</sup>
4. Insert a fully charged battery into the rectangular opening to the left of the canister openings.<sup>3</sup>
5. Ensure the sample loop is installed.<sup>4</sup>
6. Navigate to main menu.
7. Allow the HAPSITE® to boot up and run auto tune check (self-calibration).<sup>5</sup>

### HAPSITE® SEQUENCE OF OPERATION (SURVEY MODE):


1. Ensure HAPSITE is turned on and warmed up.
2. Navigate to main screen.
3. Choose "Return to Main Menu"
4. Choose "Run Method"
5. Choose JPMESG Rev 2 Methods
6. Choose JPMESG Survey
7. Ensure Tune parameters are OK,
8. Press **Run** and sample background in ambient air surrounding for about a minute to allow the background to drop and stabilize.<sup>6</sup>
9. Get a volatile organic compound (VOC) sample to test (e.g., toluene, acetone, gasoline).
10. Hold probe over sample for up to one minute while monitoring the TIC count. Look for a response (spike) and pull probe away. (Remember: TIC count over 60 million is indicative of oversaturation.)
11. Keep running the HAPSITE® for at least one minute away from the sample and allow background to drop again.
12. After the clean background has been obtained leave the HAPSITE® running in the clean area for a minimum of a minute prior to entering a suspected contaminated area.
13. When entering an area ensure the TIC count is being observed at all times, if the TIC count reaches 60,000,000 back away from the area.
14. Return to the clean area and let HAPSITE® run for 1 minute
15. Select **Escape** to end the method and return to main menu.
16. Review findings

### HAPSITE® SEQUENCE OF OPERATION (SAMPLE LOOP BLANK):

1. Ensure HAPSITE is turned on and warmed up.
2. Navigate to main screen.
3. Choose "Return to Main Menu"
4. Choose "Run Method"
5. Choose JPMESG Rev 2 Methods
6. Choose JPMESG GCMS
7. Ensure the Sample Loop is installed with the correct cover. Sample Loop cover will have **Sample Loop** written on it.
8. Select **JPMESG Loop Method**
9. Select **gc\_sl**.
10. Press **Run**.
11. HAPSITE® will start sampling as soon as the user selects the run button.
12. Sample collection time is 60 seconds, collection of sample is indicated on the bottom of the screen as "loop fill"
13. When complete, review the blank run. It should show the following:<sup>8</sup>
  - Air Peak at 1:20 +/- 10 seconds
  - Internal Standard #1 at 2:30 minutes +/- 10 seconds (TRIS)
  - Internal Standard #2 at 8:00 minutes +/- 10 seconds (BPFB)
  - No additional peaks and low background

All four criteria constitute a satisfactory blank run. See the figure below for an example of a good Sample Loop blank run with all three peaks identified and no additional peaks.





Sample Loop Blank Chromatogram

**HAPSITE® SEQUENCE OF OPERATION (TRI-BED CONCENTRATOR BLANK):**


1. Ensure HAPSITE is turned on and warmed up.
2. From Main screen, choose press the ESC button
3. Ensure that the Tri-bed concentrator is installed with groove facing up and the appropriate cover is attached. If a problem should occur when running a concentrator, the following message may appear:

**No Concentrator Installed/Incorrect Concentrator:**

- (1) Indicates the concentrator cover may not be on.
- (2) Indicates the concentrator is not being recognized; may be due to a chipped end at the base of tube. Chipped concentrator will show Low Column Pressure Warning.<sup>9</sup>

4. Choose "Run Method"
5. Choose JPMESG Rev 2 Methods
6. Choose JPMESG GCMS
7. Choose JPMESG Concentrator
8. Select **JPMESG Concentrator Clean-out (gc\_cbcl)**. Press **Run** and observe the maximum TIC during this three-minute run. If the TIC is greater than 500,000 at the end of run, repeat clean-out.
9. Note the number of clean-outs required to get TIC below 500,000, and note the actual TIC in comments.<sup>10</sup>
10. Choose "Return to Main Menu"
11. Choose "Run Method"
12. Choose JPMESG Rev 2 Methods
13. Choose JPMESG GCMS
14. Choose JPMESG Concentrator
15. Select **JPMESG Tri-bed concentrator method (gc\_cb1m)**, and press **Run**. (Check the Tune Report if you have not already done so.)
16. Sample collection time is 60 seconds, collection of sample is indicated on the bottom of the screen as "conc fill"
17. When complete, review the blank run. It should show the following:<sup>11</sup>
  - Air Peak at 1:20 +/- 10 seconds
  - Internal Standard #1 at 2:30 minutes +/- 10 seconds (TRIS)
  - Internal Standard #2 at 8:00 minutes +/- 10 seconds (BPFb)
  - No additional peaks and low background.

All four criteria constitute a satisfactory blank run. See Below for an example of a good blank run.



Tri-bed Concentrator Blank Chromatogram

**HAPSITE® SEQUENCE OF OPERATION (HEADSPACE SAMPLING SYSTEM (HSS) SET-UP METHOD):<sup>12</sup>**

1. Ensure HAPSITE® is in Extended Standby Mode.
2. Attach “Y”-Cable Power Splitter. Connect the single connector end of the cable to the Converttec, power supply. Connect one of the split ends of the cable to the left side of the HAPSITE® and the other to the back of the Headspace unit.



Back of HAPSITE® Analytical Module

3. Remove probe from the HAPSITE®. Connect the HSS transfer line and ensure that the end of the HSS transfer line with the yellow label marked “This End to HAPSITE®” is connected to HAPSITE®. Connect the end of transfer line with the white label marked “This End to Headspace” to the back of the HSS.




HAPSITE® Headspace Transfer Line

4. Insert a nitrogen canister and a charged battery into the HSS and turn on the power.

#### HAPSITE® SEQUENCE OF OPERATION (HEADSPACE TRI-BED PERFORMANCE STANDARD):

1. Select **Run** Method from Main Menu.
2. Select JPMESG GCMS Methods
3. JPMESG HeadSpace
4. Select Headspace. Select **hs\_slwgc** method.
5. HAPSITE® warm-up heaters window will appear. This process takes approximately 15–20 minutes.
6. Automatic tune will initiate (see HAPSITE® LCD screen). The message **Instrument is Tuned** should appear.
7. Measure 20 mL of deionized or sterile water into a 40 mL vial. Inject 1  $\mu$ L of the Headspace Performance Standard into the 20 mL of de-ionized water through the septum. Gently mix, and then place in the Headspace. Place a clean empty vial in the Headspace next to the vial with Performance Standard.
8. Close yellow cover and press **Run** to start method. Observe on HAPSITE® or laptop screen. Data file name will automatically be generated on HAPSITE® LCD screen.
9. After the run is complete, follow screen directions. Put needle in clean vial and press SEL to purge. Purging takes approximately two minutes.
10. Press **SEL** to view results from front panel LCD.



Headspace Tri-bed Performance Test Method

#### RECORD DATA:

1. Utilize DOEHS or equivalent as applicable.

**LOCAL REQUIREMENTS:****NOTES:**

1. Place hands on top of front panel, using thumbs, pull panel down and outward to open. Care should be taken not to tear the seal.
2. Insert instructions for canisters are located on the inside of the front panel and require the operator to press and hold the PUSH button located to the right of the containment area while inserting canister. With canister pushed in, release the button and this should engage the canister to stay in the containment area. If you can pull it out then it was not inserted properly.
3. The battery is loaded in the opening to the left of the canisters. The INFICON name will be in the upper left corner of the battery and the TEST button in the upper right corner when the battery has been inserted correctly. When the HAPSITE® is in extended standby a battery should be in the machine. The battery will be recharged while in extended standby.
4. Sample loop is located to the right of the canisters. When installing the Sample Loop do **not** over tighten.
5. When tune check is complete, *PRESS ANY BUTTON TO CONTINUE* will appear at the top of the display screen. Any button you press on the HAPSITE® will cause the display window to show the MAIN MENU.
6. TIC generally should be less than 200,000. If not, check area for interferences such as chemicals that may be in the area.
7. Instrument will continuously run until you stop it while in Survey Mode.
8. Monitoring what a normal blank looks like is one step in verifying the operation of the HAPSITE® and determining if there is a problem. If there are additional peaks in the blank spectrum, and they cannot be removed with additional blank runs, review your blank chromatogram, note the additional analytes, and contact the ESOH Service Center.
9. It is important to blow out the ferrule chamber to ensure broken pieces of the chipped tube are not imbedded.
10. Clean-outs required.
11. If there are additional peaks in the blank spectrum, and they cannot be removed with additional blank runs, AND they are not getting in the way of other analytes, note the additional analytes, and adjust your sample spectrum accordingly. Remember that in future samples, if the chemical that showed up in the blank run is sampled, there will be an increase in peak heights.
12. The Headspace Performance Standard is a test of the HAPSITE® and Headspace connections using the Tri-bed concentrator.

## PERFORMANCE CHECKLIST

### STS Line Item 4.5.2.6.3: Portable GC/MS (HAPSITE®)

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...		YES	NO
<b>START UP FROM STANDBY MODE</b>			
1. Use thumbs to open front panel of HAPSITE®?			
2. Insert purple-banded Nitrogen gas canister into the opening with the purple stripe?			
3. Insert yellow-banded Internal Standard gas canister into bottom canister opening marked with yellow stripe?			
4. Insert a fully charged battery into the rectangular opening to the left of the canister openings?			
5. Ensure the sample loop is installed?			
6. Press and hold the power button located on the outside of the HAPSITE®'s face panel?			
7. Allow the HAPSITE® to boot up and run auto tune check (self-calibration)?			
<b>HAPSITE® SEQUENCE OF OPERATION (SURVEY MODE)</b>			
1. Ensure HAPSITE is turned on and warmed up?			
2. From Main screen, choose <b>Press the ESC button?</b>			
3. Choose <b>Return to Main Menu?</b>			
4. Choose <b>Run Method?</b>			
5. Choose <b>JPMESSG Rev 2 Methods?</b>			
6. Choose <b>JPMESSG Survey?</b>			
7. Ensure Tune parameters are OK			

8. Press <b>Run</b> and sample background in ambient air surrounding for about a minute to allow the background to drop and stabilize?			
9. Get a volatile organic compound (VOC) sample to test?			
10. Hold probe over sample for up to one minute while monitoring the TIC count?			
11. Keep running the HAPSITE® for at least one minute away from the sample and allow background to drop again repeating steps 4 and 5 two or three times?			
12. After the clean background has been obtained leave the HAPSITE® running in the clean area for a minimum of a minute prior to entering a suspected contaminated area?			
13. When entering an area ensure the TIC count is being observed at all times?			
14. Return to the clean area and let HAPSITE® run for one minute?			
15. Select <b>ESC</b> to end the method and return to main menu?			
16. Review findings?			
<b>HAPSITE® SEQUENCE OF OPERATION (SAMPLE LOOP BLANK)</b>			
1. Ensure HAPSITE is turned on and warmed up?			
2. From Main screen, choose press the ESC button?			
3. Choose <b>Return to Main Menu</b> ?			
4. Choose <b>Run Method</b> ?			
5. Choose <b>JPMESSG Rev 2 Methods</b> ?			
6. Choose <b>JPMESSG GCMS</b> ?			
7. Ensure the Sample Loop is installed with the correct cover?			
8. Select <b>JPMESSG Loop Method</b> ?			
9. Select <b>gc_sl</b> ?			
10. Press <b>Run</b> ?			
11. Allow sample collection time of 60 seconds?			
12. When complete, review the blank run?			
<b>HAPSITE® SEQUENCE OF OPERATION (TRI-BED CONCENTRATOR BLANK)</b>			
1. Ensure HAPSITE® is turned on and warmed up?			
2. From Main screen, choose the <b>ESC</b> button?			

3. Ensure that the Tri-bed concentrator is installed with groove facing up and the appropriate cover is attached?			
4. Choose <b>Return to Main Menu?</b>			
5. Choose <b>Run Method?</b>			
6. Choose <b>JPMESG Rev 2 Methods?</b>			
7. Choose <b>JPMESG GCMS?</b>			
8. Choose <b>JPMESG Concentrator?</b>			
9. Select <b>JPMESG Concentrator Clean-out (gc_cbcl)?</b>			
10. Press <b>Run</b> and observe the maximum TIC during this three-minute run?			
11. Note the number of clean-outs required to get TIC below 500,000, and note the actual TIC in comments?			
12. Choose <b>Return to Main Menu?</b>			
13. Choose <b>Run Method?</b>			
14. Choose <b>JPMESG Rev 2 Methods?</b>			
15. Choose <b>JPMESG GCMS?</b>			
16. Choose <b>JPMESG Concentrator?</b>			
17. Select <b>JPMESG Tri-bed Concentrator Method (gc_cb1m)?</b>			
18. Press <b>Run?</b>			
19. Allow a sample collection time of 60 seconds?			
20. When complete, review the blank run?			
<b>HAPSITE® SEQUENCE OF OPERATION (HEADSPACE SAMPLING SYSTEM (HSS) SET-UP METHOD)</b>			
1. Ensure HAPSITE® is in Extended Standby Mode?			
2. Attach “Y”-Cable Power Splitter?			
3. Remove probe from the HAPSITE®?			
4. Connect the HSS transfer line?			
5. Ensure that the end of the HSS transfer line with the yellow label marked “This End to HAPSITE®” is connected to HAPSITE®?			
6. Connect the end of transfer line with the white label marked “This End to Headspace” to the back of the HSS?			

7. Insert a nitrogen canister and a charged battery into the HSS and turn on the power?			
<b>HAPSITE® SEQUENCE OF OPERATION (HEADSPACE TRI-BED PERFORMANCE STANDARD)</b>			
1. Select <b>Run Method</b> from Main Menu?			
2. Select <b>JPMESG GCMS Methods?</b>			
3. Select Headspace?			
4. Select <b>hs_slwqc</b> method?			
5. Wait until the message <b>Instrument Is Tuned</b> appeared?			
6. Measure 20 mL of deionized or sterile water into a 40 mL vial?			
7. Inject 1 µL of the Headspace Performance Standard into the 20 mL of de-ionized water through the septum?			
8. Gently mix, and then place in the Headspace?			
9. Place a clean empty vial in the Headspace next to the vial with Performance Standard?			
10. Close yellow cover?			
11. Press <b>Run</b> to start method?			
12. Observe on HAPSITE® or laptop screen?			
13. After the run completed, follow screen directions?			
14. Put needle in clean vial and press <b>SEL</b> to purge?			
15. Press <b>SEL</b> to view results from front panel LCD?			
<b>RECORD DATA</b>			
Utilize DOEHS or equivalent as applicable			
<b>Did the trainee successfully complete the task?</b>			

---

 TRAINEE NAME (PRINT)

---

 TRAINER NAME (PRINT)



## STS Line Item 4.5.2.6.4: Combustible Gas Meters: MSA Passport® Personal Alarm\*

### TRAINER GUIDANCE

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	None
<b>Training References:</b>	MSA Passport® Personal Alarm Instruction Manual
<b>Additional Supporting References:</b>	MSA Passport® Personal Alarm Technical Manual <a href="http://media.msanet.com/NA/USA/PortableInstruments/CombinationInstrumentsandCombustibleGasIndicators/PassportPersonalAlarm/803919.pdf">http://media.msanet.com/NA/USA/PortableInstruments/CombinationInstrumentsandCombustibleGasIndicators/PassportPersonalAlarm/803919.pdf</a>
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>• MSA Passport® Personal Alarm with fully charged battery pack/power source</li> <li>• Calibration gas</li> </ul>
<b>Specific Techniques:</b>	Conduct hands-on training and evaluation of calibration and operation of equipment with verification of steps.
<b>Criterion Objective:</b>	Given a Passport® Personal Alarm, demonstrate how to operate and calibrate it successfully completing all the checklist items with no trainer assistance.
<b>Notes:</b> * The Passport® Personal Alarm detects oxygen (O <sub>2</sub> ), carbon monoxide (CO), hydrogen sulfide (H <sub>2</sub> S), and sulfur dioxide (SO <sub>2</sub> ). The Passport® Personal Alarm detects gases and vapors in air only. It cannot measure combustible or toxic gases in reducing atmospheres, furnace stacks, or environments with inert gas backgrounds. The Passport Alarm measures combustible gases and vapors; however, it cannot measure the presence of combustible airborne mists such as lubricating oils.	

## TASK STEPS

1. Turn on Passport in clean, fresh air environment.<sup>1</sup>
2. Observe readings to verify no gas present.
3. Check battery condition.
4. Perform calibration check.<sup>2</sup>
5. Attach sampling lines and related equipment, if available and collecting a sample from a remote or inaccessible location.<sup>3</sup>
6. Expose instrument to environment.
7. Record meter readings.
8. Utilize DOEHS or equivalent.

## LOCAL REQUIREMENTS:

## NOTES:

1. When the unit is turned on it responds with the following:
  - backlight flashes
  - screen flashes
  - alarm sounds
  - alarm lights flash
  - major electronic components are tested automatically
2. Calibration checks must be made frequently if materials such as silicone, silicates, or lead-containing compounds such as leaded gasoline are suspected to be present in the tested atmosphere. If you do not recalibrate, the instrument may give false readings and endanger life and health. To perform a calibration check, do the following steps:
  - a. Attach the pump module or calibration cap to the Passport Alarm, orienting the inlet fitting to point toward the battery pack
  - b. Attach the calibration adapter to the calibration cap or pump module
  - c. Attach the regulator to the cylinder
  - d. Connect the black tubing to the regulator
  - e. Open the valve on the regulator and connect the other end of the tubing to the inlet fitting
  - f. Observe readings are within limits stated on the calibration cylinder
3. To attach probe to sampling line, follow these steps:
  - a. Grasp the probe handle by the top two sections [the large section (cap) with the MSA logo and the center section (base) with the label].
  - b. Unscrew lower section (guard) from the label section.
  - c. Feed male end of the sample line through the guard and screw into the exposed connector ring on the probe.
  - d. Screw the guard back onto the base.

## PERFORMANCE CHECKLIST

### STS Line Item 4.5.2.6.4: Combustible Gas Meters: MSA Passport® Personal Alarm

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...		YES	NO
1. Turn on Passport in clean, fresh air environment?			
2. Observe readings to verify no gas present?			
3. Check battery condition?			
4. Perform calibration check?			
5. Attach sampling lines and related equipment, if available and collecting a sample from a remote or inaccessible location?			
6. Expose instrument to environment?			
7. Record meter readings?			
8. Utilize DOEHS or equivalent.			
<b>Did the trainee successfully complete the task?</b>			

---

 TRAINEE NAME (PRINT)

---

 TRAINER NAME (PRINT)

## STS Line Item 4.5.2.6.4: Combustible Gas Meters: MSA Sirius® Multigas Detector\*

### TRAINER GUIDANCE

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	None
<b>Training References:</b>	MSA Sirius® Multigas Detector Operating Manual
<b>Additional Supporting References:</b>	<a href="http://www.msanorthamerica.com/catalog/product16577.html">http://www.msanorthamerica.com/catalog/product16577.html</a> <a href="http://www.msanorthamerica.com/">http://www.msanorthamerica.com/</a>
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>MSA Sirius® Multigas Detector with fully charged battery/power source</li> <li>Calibration gas</li> </ul>
<b>Specific Techniques:</b>	Conduct hands-on training and evaluation of calibration and operation of equipment with verification of steps.
<b>Criterion Objective:</b>	Given a Sirius® Multigas Detector, demonstrate how to operate it successfully completing all the checklist items with no trainer assistance.
<b>Notes:</b> <p>* The Sirius® Multigas Detector is designed to detect gases and vapors in air only and to detect only specified toxic gases for which a sensor is installed.</p> <p>Use only Teflon sampling lines for reactive gases such as chlorine (CL<sub>2</sub>), phosphine (PH<sub>3</sub>), ammonia (NH<sub>3</sub>), hydrogen cyanide (HCN), and for semivolatile organic compounds such as gasoline and jet fuels. Do not use silicone tubing or sampling lines. The operating manual contains additional warnings and acceptable usage limits for the unit as well as a discussion of how the unit functions.</p>	

## TASK STEPS

### Turning ON the Sirius® Multigas Detector

1. Press the **Power ON** button.<sup>1</sup>
  1. Perform Fresh Air Set Up Option for automatic zero adjustment of the Sirius® Multigas Detector sensors.<sup>2</sup>

### Verifying Pump Operation

1. Turn **ON** the Sirius® Multigas Detector.<sup>3</sup>
2. Once gas readings are displayed, plug the free end of the sampling line or probe.<sup>4</sup>
3. Check the pump before each day's use.
4. Press the **RESET/▼** button to reset the alarm and restart the pump.<sup>8</sup>

### Clearing an Alarm

1. Correct any flow blockage.
2. Press the **RESET/▼** button. The Pump will now restart.

### Conducting a Pre-Operational Check

The pre-operational check is simple and should only take about one minute. Perform this check before each day's use for each installed sensor.

1. Turn **ON** the Sirius® Multigas Detector in clean, fresh air.
2. Verify that readings indicate no gas is present.
3. Attach regulator (supplied with calibration kit) to the cylinder.
4. Connect tubing (supplied with calibration kit) to the regulator.
5. Attach other end of tubing to the instrument.
6. Open the valve on the regulator, if so equipped.
7. Determine that the reading on the Sirius® Multigas Detector display is within the limits stated on the calibration cylinder or limits pre-determined by your flight.
8. If necessary, change cylinder to introduce other calibration gases.
9. If readings are not within these limits, the Sirius® Multigas Detector requires recalibration.<sup>6</sup>

### Conducting a Calibration Check

1. Turn **ON** the Sirius® Multigas Detector in clean, fresh air.
2. Verify that readings indicate no gas is present.
3. Attach regulator (supplied with calibration kit) to the cylinder.
4. Connect tubing (supplied with calibration kit) to the regulator.
5. Attach other end of tubing to the instrument.
6. Open the valve on the regulator, if so equipped.<sup>7</sup>

### Performing Recalibration (if necessary)

1. Turn **ON** the instrument and verify that battery has sufficient life.
2. Wait until the Measure Gases page appears.
3. Push and hold the **RESET/▼** button until **CAL ZERO?** flashes on the display.
4. Push the **ON-OFF/ACCEPT** button to zero the instrument.<sup>8</sup>
5. Connect the appropriate calibration gas (MSA recommends 100ppm isobutylene) to the instrument by connecting one end of the tubing to the pump inlet on the instrument and the other end of tubing to the cylinder regulator (supplied in the calibration kit).\*
6. Open the valve on the regulator, if so equipped.
7. Push the **ON-OFF/ACCEPT** button to calibrate (span) the instrument.<sup>9</sup>
8. Remove the tubing from the instrument.

**Measuring Gas Concentrations<sup>10</sup>**

1. Expose instrument to environment
2. Calculate response factor

**Resetting Short Term Exposure Limits (STELs)<sup>11</sup>**

1. Access the STEL page.
2. Press the RESET/▼ button

**Resetting the Time Weighted Average (TWA)<sup>12</sup>**

1. Access the TWA page.
2. Press the RESET/▼ button.

**Recording data**

1. Utilize DOEHRS or equivalent.

**LOCAL REQUIREMENTS:****NOTES:**

1. The instrument displays the following information:
  - a. A self-test:
    - a. Audible alarm sounds
    - b. Alarm LEDs illuminate
    - c. Display backlight illuminates
    - d. Pump activates
    - e. Software version displays
    - f. Internal diagnostics.
  - b. Alarm setpoints:
    - a. Low
    - b. High
    - c. STEL (if activated)
    - d. TWA (if activated)
  - c. Calibration gas (expected calibration gas values)

- d. Time and date (if data logging option installed)
- e. Last CAL date (if data logging option installed) —The Sirius® Multigas Detector is equipped with a “last successful calibration date” feature. The date shown is the last date that all installed sensors were successfully calibrated. **LAST CAL** is displayed with this date in the following format: **MM/DD/YY**
- f. Instrument warm-up period
- g. Fresh Air Setup (FAS) option.

2. Persons responsible for the use of the Sirius® Multigas Detector must determine whether or not the Fresh Air Setup option should be used. The user's abilities, training and normal work practices must be considered when making this decision.

**Warning:** Do not activate the Fresh Air Setup unless you are certain you are in fresh, uncontaminated air; otherwise, inaccurate readings can occur which can falsely indicate that a hazardous atmosphere is safe. If you have any doubts as to the quality of the surrounding air, do not use the Fresh Air Setup feature. Do not use the Fresh Air Setup as a substitute for daily calibration checks. The calibration check is required to verify span accuracy. Failure to follow this warning can result in serious personal injury or death.

To perform a Fresh Air Setup, push the ON/OFF button while **ZERO?** is flashing. The Fresh Air Setup (FAS) has limits. If a hazardous level of gas is present, the Sirius® Multigas Detector ignores the FAS command and goes into alarm.

Once the instrument self check is complete, **ZERO?** flashes for 10 seconds.

If no buttons are pushed, the **ZERO?** automatically stops flashing after the 10 seconds have expired and the FAS is not performed.

To immediately skip the FAS, push the **RESET/ ▼** button.

3. The pump motor will start fast and then slows down as the instrument adjusts the power to run the pump.

4. If the pump motor shuts down and an alarm sounds, **PUMP ALARM** will flash on the display and the readings on the display may change. When the pump inlet, sample line or probe is blocked, the pump alarm must activate. If the alarm does not activate, check the sample line and probe for leaks. Once leak is fixed, re-check pump alarm by blocking flow.

5. **Warning:** Perform a blocked flow test before each day's use. Do not use the pump, sample line, or probe unless the pump alarm activates when the flow is blocked. Lack of an alarm is an indication that a sample may not be drawn to the sensors, which could cause inaccurate readings. Failure to follow the above can result in serious personal injury or death.

During operation, a pump alarm may occur when the flow system is blocked, pump is inoperative, and sample lines are attached or removed.

When the instrument is in a gas alarm, the pump alarm may not display until gas alarm is cleared.

6. The presence of other calibration gases may cause the PID to under range, indicated by dashes for the displayed **VOC** reading.

7. The reading on the Sirius® Multigas Detector display should be within the limits stated on the calibration cylinder or limits which are predetermined by the user. If necessary, change cylinder to introduce other calibration gases. If readings are not within these limits, the Sirius Multigas Detector requires recalibration.
8. Instrument must be in fresh air to perform the zero. **CAL ZERO** flashes. To skip the Zero procedure and move directly to the calibration span procedure, push the **RESET/▼** button. If no button is pushed for 30 seconds, the instrument returns to the Measure mode. Once the zeros are set, **CAL SPAN?** flashes
9. **CAL SPAN** flashes for approximately 90 seconds. If autocalibration sequence passes, the instrument beeps three times and returns to the Measure mode. To skip calibration and return to the Measure mode, push the **RESET/▼** button. If no button is pushed for 30 seconds, it will return to the Measure page.
10. **Warning:** Never let the end of the sampling line touch or go under any liquid surface. If liquid is sucked into the instrument, readings will be inaccurate and the instrument could be damaged. We recommend the use of an MSA Sample Probe (P/N 10042621, 10042622, 10040589, or equivalent) containing a special membrane filter, permeable to gas but impermeable to water, to prevent such an occurrence.

The Sirius® Multigas Detector can be equipped to detect combustible gases in the atmosphere.

a. Alarms sound when concentrations reach:

- i. Alarm Setpoint or
- ii. 100% LEL (Lower Explosive Limit), 5% CH<sub>4</sub>.

b. When the combustible gas indication reaches the Alarm Setpoint:

- i. Alarm sounds
- ii. Alarm lights flash
- iii. % LEL or CH<sub>4</sub> flag above the concentration flashes.

c. To silence the alarm, press the **RESET/▼** button. The alarm will stay silent if the alarm condition has cleared.

d. When the combustible gas indication reaches 100% LEL or 5% CH<sub>4</sub>, the LockAlarm™ circuit locks the combustible gas reading and alarm and:

- i. Alarm sounds
- ii. Alarm lights flash
- iii. 100 (or 5.00 in CH<sub>4</sub> mode) appears on the display and flashes.

e. This alarm cannot be reset with the **RESET/▼** button. After moving to a safe, fresh-air environment, reset the alarm by turning OFF the instrument and turning it ON again.

To determine a response factor for a target chemical, perform the following procedure:



1. Calibrate the Sirius Detector using isobutylene as the span gas.
2. On the monitor, set the sample gas name to isobutylene.
3. Apply a known concentration of the target chemical to the monitor and note the concentration reported in the display.
4. The response factor for the target chemical relative to isobutylene:

$$\text{RF target gas} = \frac{\text{Actual known concentration}}{\text{Concentration reported by instrument}}$$

**For example:**

A monitor is calibrated on isobutylene, and has isobutylene defined as the sample gas. When sampling 106 ppm of benzene in air, the instrument reports a concentration of 200 ppm. In this example, the response factor for benzene relative to isobutylene would be:

$$\text{RF benz} = \frac{106 \text{ ppm known conc. benzene}}{200 \text{ ppm reported}} = 0.53$$

When surveying, if benzene is selected as the sample gas in the Response Factor page, and 0.53 is entered into the monitor as the response factor, the instrument would use this response factor to automatically correct the displayed concentration into PPM benzene.

If a chemical has a response factor between zero and one, the monitor has a higher detector response for this chemical than isobutylene. If the response factor is greater than one, the monitor has a lower detector response for this chemical than isobutylene.

11. The STEL alarm is calculated over a 15-minute exposure. Calculation examples are as follows:

- Assume the detector has been running for at least 15 minutes:

- 15-minute exposure of 35 PPM:

$$\frac{(15 \text{ minutes} \times 35 \text{ PPM})}{15 \text{ minutes}} = 35 \text{ PPM}$$

- 10-minute exposure of 35 PPM

- 5-minute exposure of 15 PPM:

$$\frac{(10 \text{ minutes} \times 35 \text{ PPM}) + (5 \text{ minutes} \times 15 \text{ PPM})}{15 \text{ minutes}} = 28 \text{ PPM}$$

12. The TWA alarm is calculated over an eight-hour exposure. Calculation examples are as follows:

- 1-hour exposure of 50 PPM:

$$\frac{(1 \text{ hour} \times 50 \text{ PPM}) + (7 \text{ hours} \times 0 \text{ PPM})}{8 \text{ hours}} = 6.25 \text{ PPM}$$

- 4-hour exposure of 50 PPM  
4-hour exposure of 100 PPM:

$$\frac{(4 \text{ hours} \times 50 \text{ PPM}) + (4 \text{ hours} \times 100 \text{ PPM})}{8 \text{ hours}} = 75 \text{ PPM}$$

- 12-hour exposure of 100 PPM:

$$\frac{(12 \text{ hours} \times 100 \text{ PPM})}{8 \text{ hours}} = 150 \text{ PPM}$$

**NOTE:** The accumulated reading is always divided by eight hours.



MSA Sirius® MultiGas Detector

## PERFORMANCE CHECKLIST

### STS Line Item 4.5.2.6.4: Combustible Gas Meters: MSA Sirius® Multigas Detector

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...		YES	NO
<b><i>TURNING ON THE SIRIUS® MULTIGAS DETECTOR</i></b>			
1. Press the <b>Power ON</b> button?			
2. Perform Fresh Air Set Up Option for automatic zero adjustment of the Sirius® MultiGas Detector sensors?			
<b><i>VERIFYING PUMP OPERATION</i></b>			
1. Turn ON the Sirius® MultiGas Detector?			
2. Once gas readings were displayed, plug the free end of the sampling line or probe?			
3. Check the pump before use?			
4. Press the RESET/ ▼ button to reset the alarm and restart the pump?			
<b><i>CLEARING AN ALARM</i></b>			
1. Correct any flow blockage?			
2. Press the RESET/ ▼ button to restart the pump?			
<b><i>CONDUCTING A PRE-OPERATIONAL CHECK</i></b>			
1. Turn ON the Sirius® Multigas Detector in clean, fresh air?			
2. Verify that readings indicate no gas is present?			
3. Attach regulator (supplied with calibration kit) to the cylinder?			
4. Connect tubing (supplied with calibration kit) to the regulator?			
5. Attach other end of tubing to the instrument?			
6. Open the valve on the regulator, if so equipped?			

7. Determine that the reading on the Sirius® Multigas Detector display is within the limits stated on the calibration cylinder or limits pre-determined by your flight?			
8. If necessary, change cylinder to introduce other calibration gases?			
9. If readings are not within these limits, the Sirius® Multigas Detector requires recalibration?			
<b>CONDUCTING A CALIBRATION CHECK</b>			
1. Turn ON the Sirius Multigas Detector in clean, fresh air?			
2. Verify that readings indicate no gas is present?			
3. Attach regulator (supplied with calibration kit) to the cylinder?			
4. Connect tubing (supplied with calibration kit) to the regulator?			
5. Attach other end of tubing to the instrument?			
6. Open the valve on the regulator, if so equipped?			
<b>PERFORMING RECALIBRATION (IF NECESSARY)</b>			
1. Turn <b>ON</b> the instrument and verify that battery has sufficient life?			
2. Wait until the Measure Gases page appears?			
3. Push and hold the <b>RESET/▼</b> button until <b>CAL ZERO?</b> flashes on the display?			
4. Push the <b>ON-OFF/ACCEPT</b> button to zero the instrument?			
5. Connect the appropriate calibration gas to the instrument by connecting one end of the tubing to the pump inlet on the instrument and the other end of tubing to the cylinder regulator (supplied in the calibration kit)?			
6. Open the valve on the regulator, if so equipped?			
7. Push the <b>ON-OFF/ACCEPT</b> button to calibrate (span) the instrument?			
8. Remove the tubing from the instrument?			
<b>MEASURING GAS CONCENTRATIONS</b>			
1. Expose instrument to environment?			
2. Calculate a response factor?			
<b>RESETTING SHORT TERM EXPOSURE LIMITS (STELs)</b>			
1. Access the STEL page			
2. Press the RESET/▼ button			
<b>RESETTING THE TIME WEIGHTED AVERAGE (TWA)</b>			

1. Access the TWA page			
2. Press the RESET/▼ button			
<b>RECORDING DATA</b>			
1. Utilize DOEHS or equivalent.			
<b>Did the trainee successfully complete the task?</b>			

---

TRAINEE NAME (PRINT)

---

TRAINER NAME (PRINT)

---

**STS Line Item 4.5.2.7: Calibrate / Operate air sampling pumps  
(Low/High flow pump)**

---

**TRAINER GUIDANCE**

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	None
<b>Training References:</b>	<ul style="list-style-type: none"> <li>• <i>Fundamentals of Industrial Hygiene</i>, 5<sup>th</sup> Edition, Chapter 16.</li> </ul>
<b>Additional Supporting References:</b>	<ul style="list-style-type: none"> <li>• <i>NIOSH Manual of Analytical Methods</i>, Chapter D.</li> </ul>
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>• Training scenario.</li> <li>• Electronic flow meter.</li> <li>• Burette.</li> <li>• Burette stand.</li> <li>• Beaker of soap solution.</li> <li>• Air sampling train.</li> <li>• Stopwatch.</li> <li>• AF Form 2750 or equivalent.</li> <li>• Paper and writing utensil.</li> </ul>
<b>Specific Techniques:</b>	Conduct hands-on training and evaluation.
<b>Criterion Objective:</b>	Given a scenario, air sampling pump, calibrator, calculator, and supplies, calibrate an air sampling pump to a designated flow rate successfully completing all checklist items with limited trainer assistance on only the hardest parts.
<b>Notes:</b>  1. See website at <a href="http://www.osha.gov/dts/osta/otm/otm_ii/otm_ii_1.html#appendix_ii_1-1">http://www.osha.gov/dts/osta/otm/otm_ii/otm_ii_1.html#appendix_ii_1-1</a>	

## TASK STEPS

1. Turn on pump and allow to run for 5 minutes before calibration.
2. Check the battery.
3. Assemble sample train.
  - Determine sample media.
  - Identify proper air flow direction through sample media. Attach the outlet end of the sample media to the inlet valve on the pump with a piece of Tygon tubing of adequate length.
  - Assemble the components of the sample train as shown in the Fundamentals of Industrial Hygiene, Figure 16-16.
4. Identify the components of the calibration apparatus: burette, burette stand, and beaker of soap solution?
5. Determine calibration volume and calculate time (T) for a bubble to run the volume (see notes 1 & 2).
6. Clean the burette and wet the inside with soap solution or water.
7. Assemble the components of the calibration apparatus as shown in the Fundamentals of Industrial Hygiene, Figure 16-17.<sup>3</sup>
8. Draw two or three bubbles up the length of the burette to ensure at least one bubble completes its run.
9. Adjust pump rotometer, if available, to desired flow rate.
10. Draw a soap bubble and, using a stop watch, measure the time it takes to get from zero to the desired calibration volume (100mL or 1,000mL).
11. Adjust the flow rate if the time is not within the range of accuracy (within  $\pm 1$  of the time corresponding to the desired flow rate)?
12. Once correct flow rate is obtained, repeat the determination at least twice.
13. Calculate the average flow rate.
14. Record the following calibration data: volumes measured, elapsed times, air temperature, atmospheric pressure, make, model, and serial number of sampling pump, collection device used, name, date, and time of person performing calibration.

### LOCAL REQUIREMENTS:

In instances where trainee is using manufacturer's instructions to calibrate an air sampling pump, it is recommended that the trainer develop an internal checklist following the manufacturer's instructions to evaluate the trainee.

### NOTES:

1. To calibrate high-volume pumps use the 0 to 1000 ml mark. To calibrate low-flow pumps use 0 to 100 ml mark.
2.  $Flow\ Rate\ (FR) = \frac{Volume(V)}{Time\ (T)}$
3. Attach the inlet end of the media to the top of the calibrator using another piece of Tygon tubing<sup>4</sup>. If media is a cassette filter, use a large jar with outlet end of media suspended in a jar through the opening in the lid, and inlet tube from jar to the calibrator.

**TRAINEE REVIEW QUESTIONS**

---

**STS Line Item 4.5.2.7: Calibrate / Operate air sampling pumps  
(Low/High flow pump)**

---

1. When should air sampling equipment be calibrated?

2. Why must you use the same media for calibration as you do for sampling?

3. Why would a secondary calibration device be used?

4. How and when can a rotometer be used for evaluation of pump efficiency?



**PERFORMANCE CHECKLIST**


---

**STS Line Item 4.5.2.7: Calibrate / Operate air sampling pumps  
(Low/High flow pump)**

---

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...		YES	NO
1. Turn on pump and allow to run for 5 minutes before beginning calibration steps?			
2. Check the battery?			
3. Assemble sample train as shown in Volume 3 of CDCs , Figure 3-19?			
4. Identify the components of the calibration apparatus: burette, burette stand, and beaker of soap solution?			
5. Determine calibration volume and calculate time for a bubble to run the volume?			
6. Clean the burette and wet the inside with soap solution or water?			
7. Assemble the components of the calibration apparatus as shown in the Fundamentals of Industrial Hygiene, Figure 16-17?			
8. Draw two or three bubbles up the length of the burette to ensure at least one bubble completes its run?			
9. Adjust pump rotometer, if available, to desired flow rate?			
10. Draw a soap bubble and, using a stop watch, measure the time it takes to get from zero to the desired calibration volume (100mL or 1,000mL)?			
11. Adjust the flow rate if the time is not within the range of accuracy (within $\pm 1$ of the time corresponding to the desired flow rate)?			
12. Repeat the determination at least twice once correct flow rate was obtained?.			
13. Calculate the average flow rate?			
14. Record the following calibration data: volumes measured, elapsed times, air temperature, atmospheric pressure, make, model, and serial number of sampling pump, collection device used, name, date, and time of person performing calibration?			
<b>Did the trainee successfully complete the task?</b>			

---

 TRAINEE NAME (PRINT)

---

 TRAINER NAME (PRINT)

**ANSWERS**

1. When should air sampling equipment be calibrated?

A: Always calibrate the air sampling equipment before starting any sample collection.

A post calibration is performed after sampling is complete. This should be performed before recharging the pump.

(Source: Career Development Course 4B051, Bioenvironmental Engineering Journeyman)

2. Why must you use the same media for calibration as you do for sampling?

A: It is important that the sampling train contain the same type of media that will be used to conduct air sampling because each media causes a different/unique pressure drop; the pressure drop can affect the sampling pump's flow rate

(Source: Career Development Course 4B051, Bioenvironmental Engineering Journeyman)

3. Why would a secondary calibration device be used?

A: Secondary standards are typically used to calibrate sampling pumps in the field when it is inconvenient or impractical to use a primary standard.

(Source: Career Development Course 4B051, Bioenvironmental Engineering Journeyman)

4. How and when can a rotometer be used for evaluation of pump efficiency?

A: They can be used to estimate whether a pump is still pulling the same airflow it was when it was calibrated. After calibration, mark the position of the rotameter so it can be periodically checked while sampling. If collecting consecutive samples, a good time to do this is when switching media.

(Source: Career Development Course 4B051, Bioenvironmental Engineering Journeyman)

## STS Line Item 4.5.2.8: Collect area air samples\*

### TRAINER GUIDANCE

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	<ul style="list-style-type: none"> <li>• Completion of Journeyman TM 4.5.2.4 Determine or establish air sampling strategies.</li> <li>• Completion of Journeyman TM 4.5.2.7 Calibrate air sampling pumps.</li> </ul>
<b>Training References:</b>	<ul style="list-style-type: none"> <li>• <i>Fundamentals of Industrial Hygiene</i>, 5th edition, Chapter 16.</li> <li>• Equipment User's Manual.</li> <li>• DOEHS IH Module/Technical Guide</li> </ul>
<b>Additional Supporting References:</b>	<i>NIOSH Manual of Analytical Methods</i> , most current edition.
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>• Occupational/industrial work environment.</li> <li>• High-volume sampling pump, calibrated in accordance with Journeyman item #4.5.2.7</li> <li>• Labeling material.</li> <li>• Paper and writing utensil.</li> <li>• <i>NIOSH Manual of Analytical Methods</i>, most current edition.</li> <li>• Equipment User's Manual.</li> </ul>
<b>Specific Techniques:</b>	Conduct hands-on training and evaluation.
<b>Criterion Objective:</b>	Given a high volume sampling pump, collect an area air sample successfully completing all checklist items with no trainer assistance.

**Notes:**

\*This QTP is limited to the task steps involved in collecting area air samples using indirect instruments – high volume sampling pumps. Area samples can be used to provide a good indication of the airborne concentration of a contaminant in a room/area over a relatively long time (extended sampling operations). The focus will be on the steps for collecting the area sample and not the instruments used to collect the sample. Outside of the RADeCOs (training available on-line at Med+Learn) and XMXs, bases will likely have one of the following:

1. Leland Legacy Pump (5 to 15 L/min)
  - <http://www.skinc.com/pumps/100-3000.asp>
  - Replaces Mini-Vols.
2. Rotary Vane Pump (to 32 L/min)
  - <http://www.staplex.com/airsamplers/asbestosareaandmicrobial/asbestos.htm>
  - <http://www.skinc.com/pumps/228-505.asp>
  - Used in area sampling of asbestos and bioaerosols.
3. Aircon-2 Kits (2-30 L/min)
  - [http://www.sensidyne.com/documents/AirCon-2\\_Area\\_Sampling\\_Pump\\_Datasheet.pdf](http://www.sensidyne.com/documents/AirCon-2_Area_Sampling_Pump_Datasheet.pdf)
  - Used in area sampling of asbestos and bioaerosols.

## TASK STEPS

1. Identify air sampling strategy.<sup>1</sup>
2. Select appropriate sampling pump.<sup>2</sup>
3. Place pump in pre-determined sampling location.<sup>3</sup>
4. Perform initial operation check of sampling pump.
5. Attach and configure sampling media correctly.<sup>4</sup>
6. Turn on pump and record start time.
7. Prepare blank samples.
8. Replace media, as necessary.<sup>5</sup>
9. Check sampling pump periodically during sampling to ensure the pump is still pulling the desired flow rate.
10. Record pertinent sampling data throughout the sampling event.<sup>6</sup>
11. Turn off pump at the end of the sampling period.
12. Remove and seal final media from sampling train and properly label.
13. Perform post-calibration process, if necessary.<sup>7</sup>
14. Utilize OEHMIS (DOEHRS or equivalent) as applicable.

### LOCAL REQUIREMENTS:

### NOTES:

1. Prior to conducting sampling, a sampling strategy should be developed to measure the “worst case” in accordance with task steps outlined in Journeyman Training Module OEH 5-1.
2. The desired flow rate will determine the sampling pump required. The sampling pump used to collect the sample must be compatible with the sampling needs and the media used. Specifically, the pump must be capable of maintaining the desired flow rate over the time period needed using the sampling media specified. Also, pumps that are to be used in potentially explosive atmospheres must be “intrinsically safe.”
3. Some sampling events may require pumps to be calibrated using the specified media prior to conducting area air sampling. Calibration task steps are covered in Journeyman Training Module OEH 5-4. Not all area sampling situations will require pumps to be pre-calibrated, for example, when sampling for radiological contamination during a broken arrow incident, you simply annotate the flow rate when the pump is turned on and off.
4. The sampling method will dictate any special requirements for configuring media (e.g., angle or height).
5. Cap/seal media and properly label each sample as it is removed from the sample train.
6. Pertinent data includes: Sampling narrative, start/stop times for each sample; initial and final air temperatures; relative humidity; and atmospheric pressure.
7. After sampling where sampling strategy required a specified flow rate, before you recharge the pump, perform the same calibration steps, outlined in Journeyman Training OEH Module 5-4, to ensure the flow rate did not change. If it has changed, use the lowest flow rate of the two for calculating the volume collected because that is the most conservative.

**TRAINEE REVIEW QUESTIONS**

---

**STS Line Item 4.5.2.8: Collect area air samples**

---

1. What determines the choice of sampling instrument?

2. What pertinent sampling data should be recorded?

3. When will special requirements for configuring media (e.g., angle or height) be used?

4. Why is area air sampling conducted versus personnel air sampling?

## PERFORMANCE CHECKLIST

### STS Line Item 4.5.2.8: Collect area air samples

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...		YES	NO
1. Identify sampling strategy?			
2. Select appropriate sampling pump?			
3. Place pump in pre-determined sampling location?			
4. Perform initial operation check of sampling pump?			
5. Attach and configure sampling media, as appropriate?			
6. Turn on pump and record start time?			
7. Prepare blank samples?			
8. Replace media, as necessary?			
9. Check sampling pump periodically during sampling to ensure the pump is still pulling the desired flow rate?			
10. Record pertinent sampling data throughout the sampling event?			
11. Turn off pump at the end of the sampling period?			
12. Remove and seal final media from sampling train and properly label?			
13. Perform post-calibration process, if necessary?			
14. Utilize OEHMIS (DOEHRS or equivalent) as applicable			
<b>Did the trainee successfully complete the task?</b>			

TRAINEE NAME (PRINT)

TRAINER NAME (PRINT)

## ANSWERS

1. What determines the choice of sampling instrument?

A:

- reason for sampling
- capabilities of sampling instrument
- chemical/hazard
- projected length of sample time
- facility/work area layout
- location and movement of workers
- location of any control measures
- environmental conditions

(Source: Career Development Course 4B051)

2. What pertinent sampling data should be recorded?

A:

- Sampling narrative
- Stop/start times for each sample
- Initial and final air temperatures
- Relative humidity
- Atmospheric pressure
- DOEHS

(Source: DOEHS IH Module/Technical Guide, How to Enter General Air Samples)

3. When will special requirements for configuring media (e.g., angle or height) be used?

A: When the sampling method dictates.

(Source: NIOSH Manual of Analytical Methods (NMAM), each method will be different if applicable)

4. Why is area air sampling conducted versus personnel air sampling?

A: Collecting integrated samples for laboratory analysis can be used to provide a good indication of the airborne concentration of a chemical contaminant in a room/area over a relatively long time. It can also help to locate the source of exposure or evaluate the effectiveness of controls.

(Source: Career Development Course 4B051 and Fundamentals of Industrial Hygiene 5<sup>th</sup> Edition, Chapter 16 )

## STS Line Item 4.5.2.9: Collect breathing zone air samples\*

### TRAINER GUIDANCE

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	<ul style="list-style-type: none"> <li>• Completion of Journeyman Item #4.5.2.4 Determine or establish air sampling strategies.</li> <li>• Completion of Journeyman, Item #4.5.2.7 Calibrate air sampling pumps.</li> </ul>
<b>Training References:</b>	<ul style="list-style-type: none"> <li>• <i>Fundamentals of Industrial Hygiene</i>, 5th Edition, Chapter 16.</li> <li>• Equipment User's Manual.</li> </ul>
<b>Additional Supporting References:</b>	NIOSH <i>Manual of Analytical Methods</i> , most current edition.
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>• Individual for sampling.</li> <li>• Personal air sampling pump, calibrated in accordance with TRAINING MODULE OEH 5-4.</li> <li>• Equipment User's Manual.</li> <li>• Labeling material.</li> <li>• Tape, clip or pin.</li> <li>• Paper and writing utensil.</li> <li>• NIOSH <i>Manual of Analytical Methods</i>, most current edition.</li> </ul>
<b>Specific Techniques:</b>	Conduct hands-on training and evaluation.
<b>Criterion Objective:</b>	Given personal air sampling pump, collect a breathing zone air sample successfully completing all checklist items with no trainer assistance.
<b>Notes:</b> *Personal air sampling is the preferred method of evaluating an individual's exposure. The sampling device is placed as close as possible to the breathing zone of the individual. Personal monitoring is typically done during a specific time period, often an 8-hour shift or a 15-minute period, to measure a particular individual's exposure and to ensure compliance with established OEELs.	



## TASK STEPS

1. Identify sampling strategy.<sup>1</sup>
2. Select the appropriate personal air sampling pump.<sup>2</sup>
3. Brief individual on the purpose and procedures for sampling.
4. Field-check the sampling pump to verify operational.<sup>3</sup>
5. Assemble sample train in accordance with Journeyman Training Module OEH 5-4.
6. Attach the pre-calibrated sampling pump to the belt or pants of the individual being sampled.<sup>4</sup>
7. Attach the sample media within the individual's breathing zone.<sup>5</sup>
8. Tape or pin the tubing to clothing to permit ease of movement.
9. Ensure media is in proper sampling position and the inlet port faces outward.
10. Turn on the pump and record start time.
11. Prepare blank samples
12. Replace the media, as necessary.<sup>6</sup>
13. Check sampling pump periodically during sampling to ensure the pump is still pulling the same airflow (flow rate) it was when it was calibrated.
14. Record pertinent sampling data throughout the process.<sup>7</sup>
15. Turn off pump at the end of the sampling period.
16. Remove the pump and media from the individual when sampling is complete.
17. Remove and seal final media from the sampling train and properly label.
18. Perform post-calibration process.<sup>8</sup>
19. Utilize OEHMIS (DOEHRS or equivalent) as applicable.

## LOCAL REQUIREMENTS:

## NOTES:

1. Prior to conducting sampling, a sampling strategy should be developed to measure the "worst case" in accordance with task steps outlined in Journeyman Training Module OEH 5-1.
2. The desired flow rate will determine the sampling pump required. The sampling pump used to collect the sample must be compatible with the sampling needs and the media. The pump must also be capable of maintaining the desired flow rate over the time needed using the sampling media specified. Pumps that are to be used in potentially explosive atmospheres must be "intrinsically safe."
3. Briefly turn sampling pump on to verify it is working properly.
4. Prior to beginning any sampling event, pumps must be calibrated using the specified media. Calibration task steps are covered in Journeyman Training Module OEH 5-4. Also, personal air sampling pumps should be placed on the opposite side of the body from the hand of preference. Therefore, if the individual is right-handed, then place the sampling pump on their left side and vice-versa.
5. Like the sampling pump, the media and tubing are also placed on the opposite side of the body from the hand of preference.
6. Cap/seal media and properly label each sample as it is removed from the sampling train.
7. Pertinent data includes: Sampling narrative, start/stop times for each sample; initial and final air temperatures; relative humidity; and atmospheric pressure.
8. After sampling, before you recharge the pump, perform the same calibration steps outlined in Journeyman Training Module OEH 5-4, to ensure the flow rate did not change. If it has changed, use the lowest flow rate of the two for calculating the volume collected because that is the most conservative.

**TRAINEE REVIEW QUESTIONS**

---

**STS Line Item 4.5.2.9: Collect breathing zone air samples**

---

- |  |
|--|
| 1. How do you make the choice of sampling pump?  |
| 2. Why do you periodically check the sampling pump during sampling?  |
| 3. Under what circumstances would collection of a breathing zone air sample continue during a worker's lunch time? |
| 4. What, if any, pertinent data will be documented?  |

## PERFORMANCE CHECKLIST

### STS Line Item 4.5.2.9: Collect breathing zone air samples

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...		YES	NO
1. Identify sampling strategy?			
2. Select the appropriate personal air sampling pump?			
3. Brief individual on the purpose and procedures for sampling?			
4. Field-check the sampling pump to verify operational?			
5. Assemble sample train in accordance with TRAINING MODULE 5-4?			
6. Attach the pre-calibrated sampling pump to the belt or pants of the individual being sampled?			
7. Attach the sample media within the individual's breathing zone?			
8. Tape or pin the tubing to clothing to permit ease of movement?			
9. Ensure media is in proper sampling position and the inlet port faces outward?			
10. Turn on the pump and record start time?			
11. Prepare blank samples?			
12. Replace the media, as necessary?			
13. Check sampling pump periodically during sampling to ensure the pump is still pulling the same airflow (flow rate) it was when it was calibrated?			
14. Record pertinent sampling data throughout the process?			
15. Turn off pump at the end of the sampling period?			
16. Remove the pump and media from the individual when sampling is complete?			
17. Remove and seal final media from the sampling train and properly label?			
18. Perform post-calibration process?			

19. Utilize OEHMIS (DOEHRS or equivalent) as applicable?			
<b>Did the trainee successfully complete the task?</b>			

---

TRAINEE NAME (PRINT)

---

TRAINER NAME (PRINT)

**ANSWERS**

1. How do you make the choice of sampling pump?

A: NMAM

(Source: NMAM, each method will tell you what type of media to use.)

2. Why do you periodically check the sampling pump during sampling?

A: You should remain at the workplace during the entire air sampling process so you can monitor the pump's flow rate, sampling train and make noteworthy observations concerning the process.

(Source: Career Development Course 4B051)

3. Under what circumstances would collection of a breathing zone air sample continue during a worker's lunch time?

A: You do not normally sample during lunch unless the person stays in the area of concern. If they do not stay in the area, turn the pump off at the start of the lunch period and seal or remove the sample media to prevent cross-contamination. It is not always necessary to remove the rest of the sampling train unless the individual prefers to remove the pump and tube during lunch. After lunch, resume sampling with the same media or use new media (if you have reached or are close to reaching the maximum air volume). If you do not sample during lunch, the time is not used in your TWA calculations.

(Source: Career Development Course 4B051)

4. What, if any, pertinent data will be documented?

A: Make periodic observations for the sample narrative. Observations and a documented narrative are important since the sample results will reflect worker habits, movements, and behavior in relation to the source(s) of contamination.

(Source: Career Development Course 4B051)

---

**STS Line Item 4.5.2.10: Calculate equivalent OEELs\***


---

**TRAINER GUIDANCE**

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	None
<b>Training References:</b>	<ul style="list-style-type: none"> <li>• <i>Patty's Industrial Hygiene and Toxicology</i>, 6.1 Brief and Scala Model and 6.2 OSHA Model.</li> <li>• American Conference of Governmental Industrial Hygienist (ACGIH), <i>TLVs® and BEIs®</i> (guidebook), most current edition.</li> </ul>
<b>Additional Supporting References:</b>	<ul style="list-style-type: none"> <li>• Air Force Manual (AFMAN) 48-146, <i>Occupational and Environmental Health Program Management</i>, 9 Oct 2012, Attachment 4.</li> <li>• Air Force Manual (AFMAN) 48-155, <i>Occupational and Environmental Health Exposure Controls</i>, 1 Oct 2008, Chapter 1.</li> </ul>
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>• Sampling data.</li> <li>• American Conference of Governmental Industrial Hygienist (ACGIH), <i>TLVs® and BEIs®</i> (guidebook), most current edition.</li> <li>• Calculator.</li> </ul>
<b>Specific Techniques:</b>	Conduct hands-on training and evaluation.
<b>Criterion Objective:</b>	Given a sampling data scenario, calculate equivalent OEELs successfully completing all checklist items with no trainer assistance.
<b>Notes:</b> *OEELs are based on the assumption that exposure occurs for an 8-hour period after which the body is no longer exposed but allowed to recover for the next 16 hours. Where the worker is exposed for more than 8-hours in a day, these assumptions do not hold true. Numerous biological factors come into play when adjusting the OEEL. The booklet produced each year by the American Conference of Governmental Industrial Hygienist (ACGIH), Threshold Limit Values (TLVs) and Biological Exposure Indices (BEIs), should be consulted to ensure it is appropriate to adjust the limit. For example, it is unnecessary to adjust limits where they are based on odor. Although limits can be adjusted downwards to accommodate longer periods of exposure, standards can never be adjusted upwards to accommodate shorter periods of exposure.	

## TASK STEPS

1. Select appropriate OEEL.
2. Determine total number of hours worked.<sup>1</sup>
3. Select the appropriate equation.<sup>2</sup>
4. Substitute hours worked per day (h) or week (hw) into the equation.
5. Solve to determine equivalent OEEL.

### LOCAL REQUIREMENTS:

### NOTES:

1. Most often exposure limits are based on the conventional 8-hour day and 40-hour week. When you encounter non-standard (extended) work shifts, OEELs may be adjusted to account for the longer exposures. Adjustments can be made for both daily and weekly exposures.

2. Formulas:

#### Brief & Scala Model:

The Brief and Scala model is the preferred method for a variety of reasons:

- Easy to use.
- Takes into account increased hours of exposure and decreased recovery time.
- Most conservative model.
- Results in the greatest reduction of the exposure limit.

#### Daily adjustment of exposure limit:

$$\text{Adjusted exposure standard (TWA)} = \left\{ \frac{8}{h} \times \left( \frac{24 - h}{16} \right) \right\} \times \text{listed TWA}$$

Where  $h$  = hours worked per day.

#### Weekly adjustment of limit:

$$\text{Weekly Reduction Factor} = \left\{ \frac{40}{hw} \times \left( \frac{168 - hw}{128} \right) \right\}$$

Where  $hw$  = hours worked per week

$$\text{Adjusted Exposure Limit} = 8 \text{ hr OEEL} \times \text{Weekly Reduction Factor}$$

#### OSHA Model:

#### Daily adjustment of exposure limit:

$$\text{Adjusted OEEL}_{\text{daily}} = \text{OEEL} \times \frac{8 \text{ hr}}{h}$$

Where  $h$  = total hours worked.

#### Weekly adjustment of exposure limit:

$$\text{Adjusted OEEL}_{\text{weekly}} = \text{OEEL} \times \frac{40 \text{ hr}}{h}$$

Where  $h$  = total hours worked.

**TRAINEE REVIEW QUESTIONS**

---

**STS Line Item 4.5.2.10: Calculate equivalent OEELs**

---

1. Calculate the equivalent OEEL using the Brief & Scala method for an employee that worked a 12-hour shift during which you collected samples for a contaminant that has an OEEL of  $0.05 \text{ mg/m}^3$ .

2. Calculate the equivalent OEEL using the OSHA method for an employee that worked five (5) 12-hour shifts which you collected samples for a contaminant that has an OEEL of 200 ppm.



## PERFORMANCE CHECKLIST

### STS Line Item 4.5.2.10: Calculate equivalent OEELs

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...	YES	NO
1. Select appropriate OEEL?		
2. Determine total number of hours worked?		
3. Select the appropriate equation?		
4. Substitute hours worked per day (h) or week (hw) into the equation?		
5. Solve to determine equivalent OEEL?		
<b>Did the trainee successfully complete the task?</b>		

---

 TRAINEE NAME (PRINT)

---

 TRAINER NAME (PRINT)

**ANSWERS**

1. Calculate the equivalent OEEL using the Brief & Scala method for an employee that worked a 12-hour shift during which you collected samples for a contaminant that has an OEEL of 0.05 mg/m<sup>3</sup>.

A:

$$\text{Adjusted exposure standard (TWA)} = \left\{ \frac{8}{12} \times \left( \frac{24 - 12}{16} \right) \right\} \times 0.05$$

$$\text{Adjusted exposure standard (TWA)} = \left( \frac{8}{12} \times \frac{12}{16} \right) \times 0.05$$

$$\text{Adjusted exposure standard (TWA)} = \frac{96}{192} \times 0.05$$

$$\text{Adjusted exposure standard (TWA)} = 0.5 \times 0.05$$

$$\text{Adjusted exposure standard (TWA)} = 0.025 \text{ mg/m}^3$$

(Source: Note #2 of this QTP)

2. Calculate the equivalent OEEL using the OSHA method for an employee that worked five (5) 12-hour shifts which you collected samples for a contaminant that has an OEEL of 200 ppm.

A:

$$\text{Adjusted OEEL}_{\text{weekly}} = 200 \text{ ppm} \times \frac{40 \text{ hr}}{60 \text{ hr}}$$

$$\text{Adjusted OEEL}_{\text{weekly}} = 200 \text{ ppm} \times 0.67 \text{ (rounded)}$$

$$\text{Adjusted OEEL}_{\text{weekly}} = 134 \text{ ppm}$$

(Source: Note #2 of this QTP)

---

**STS Line Item 4.5.2.11: Convert raw concentrations (i.e., grams to mg/m<sup>3</sup>)\***


---

**TRAINER GUIDANCE**

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	None
<b>Training References:</b>	<ul style="list-style-type: none"> <li>American Conference of Governmental Industrial Hygienist (ACGIH), <i>TLVs® and BEIs®</i> (guidebook), most current edition.</li> </ul>
<b>Additional Supporting References:</b>	None
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>Sample results.</li> <li>Calculator.</li> </ul>
<b>Specific Techniques:</b>	Conduct hands-on training and evaluation.
<b>Criterion Objective:</b>	Given sampling results, convert concentrations successfully completing all checklist items with no trainer assistance.
<p><b>Notes:</b> *When you receive your air sampling results back from the analytical laboratory, in most cases you will need to calculate the TWA and compare the results to the applicable OEEL. For those cases where the laboratory uses the air volume you provided and calculates the concentration in milligrams per cubic meter (mg/m<sup>3</sup>) or parts per million (ppm), at normal temperature and pressure (NTP), no corrections are required; you can simply compare your results directly to the applicable OEEL as long as the OEEL is in the same units. If the units are not the same, you will need to use one of the formulas provided below to convert to the same units as the OEEL: mg/m<sup>3</sup> or ppm.</p> <p>In situations where the laboratory reported your results as a weight of contaminant collected on the sample media, such as milligrams (mg) or micrograms (µg), these results cannot be compared to the OEEL. When this happens, you must first determine the volume of air drawn through the sample then calculate the mass/volume concentration in mg/m<sup>3</sup>.</p> <p>Remember, the units must be the same in order to make a comparison.</p>	

## TASK STEPS

1. Select the appropriate equation.<sup>1</sup>
2. Substitute the known variables into the appropriate equation.
3. Solve to convert given results to desired units.

### LOCAL REQUIREMENTS:

### NOTES:

1. Conversion Formulas:

#### mg/m<sup>3</sup> to ppm:

$$\text{mg/m}^3 = \frac{\text{Molecular Weight (MW) of substance} \times \text{Sample results in ppm}}{24.45}$$

Where 24.45 = a constant and represents the molar volume of air liters at NTP conditions (25°C and 760 torr).

#### ppm to mg/m<sup>3</sup>:

$$\text{ppm} = \frac{24.45 \times \text{Sample results in mg/m}^3}{\text{Molecular Weight (MW) of substance}}$$

Where 24.45 = a constant and represents the molar volume of air liters at NTP conditions (25°C and 760 torr).

#### volume:

$$\text{Volume (liters)} = \text{flow rate (lpm)} \times \text{time}$$

#### liters to cubic meters:

$$\text{Volume (meters}^3\text{)} = \frac{\text{liters}}{1} \times \frac{1 \text{ meter}^3}{1000 \text{ liters}}$$

#### mass/volume concentration in mg/m<sup>3</sup>:

$$\text{Concentration (mg/m}^3\text{)} = \frac{\text{mass reported (mg)}}{\text{volume (m}^3\text{)}}$$

---

**TRAINEE REVIEW QUESTIONS**

---

---

**STS Line Item 4.5.2.11: Convert raw concentrations (i.e., grams to  $\text{mg}/\text{m}^3$ )**

---

1. You just received your air sample results from the analytical laboratory. You were sampling for benzene. The sample results were returned as  $1.2 \text{ mg}/\text{m}^3$  but the OEEL for benzene is listed as ppm, so you will need to convert the concentration in order to compare it to the standard.

2. You just received your air sample results from the analytical laboratory. You were sampling for methyl ethyl ketone (MEK). The sample results were returned as 38 ppm but the OEEL for MEK is listed as  $\text{mg}/\text{m}^3$  so you will need to convert the concentration in order to compare it to the standard.

3. Your sample flow rate was 1.0 liter/minute (lpm) and your total sampling time was 90 minutes, what is your sample volume?

4. Using the sample volume from Question #3, convert the liters to cubic meters ( $\text{m}^3$ ).

5. Your sample results have returned from the laboratory, which reported the results as a mass of 18 mg. Using the converted sample volume from Question #4, what are your results in  $\text{mg}/\text{m}^3$ ?

**PERFORMANCE CHECKLIST**

---

**STS Line Item 4.5.2.11: Convert raw concentrations (i.e., grams to mg/m<sup>3</sup>)**

---

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...	YES	NO
1. Select the appropriate equation?		
2. Substitute the known variables into the appropriate equation?		
3. Solve to convert given results to desired units?		
<b>Did the trainee successfully complete the task?</b>		

---

TRAINEE NAME (PRINT)

---

TRAINER NAME (PRINT)

**ANSWERS**

1. You just received your air sample results from the analytical laboratory. You were sampling for benzene. The sample results were returned as 1.2 mg/m<sup>3</sup> but the OEEL for benzene is listed as ppm, so you will need to convert the concentration in order to compare it to the standard.

A:

$$ppm = \frac{24.45 \times \text{Sample results in mg/m}^3}{\text{Molecular Weight (MW) of substance}}$$

$$ppm = \frac{24.45 \times 1.2 \text{ mg/m}^3}{78.11}$$

$$ppm = 0.38 \text{ (rounded)}$$

(Source: Note 2 of this QTP)

2. You just received your air sample results from the analytical laboratory. You were sampling for methyl ethyl ketone (MEK). The sample results were returned as 38 ppm but the OEEL for MEK is listed as mg/m<sup>3</sup> so you will need to convert the concentration in order to compare it to the standard.

A:

$$\text{mg/m}^3 = \frac{\text{Molecular Weight (MW) of substance} \times \text{Sample results in ppm}}{24.45}$$

$$\text{mg/m}^3 = \frac{72.10 \times 38 \text{ ppm}}{24.45}$$

$$\text{mg/m}^3 = 112 \text{ (rounded)}$$

(Source: Note 1 of this QTP)

1. Your sample flow rate was 1.0 liter/minute (lpm) and your total sampling time was 90 minutes, what is your sample volume?

A:

$$\text{Volume (liters)} = \text{flow rate (lpm)} \times \text{time}$$

$$\text{Volume (liters)} = 1.0 \text{ lpm} \times 90 \text{ mins}$$

$$\text{Volume} = 90 \text{ liters}$$

(Source: Note 3 of this QTP)



4. Using the sample volume from Question #3, convert the liters to cubic meters ( $m^3$ ).

A:

$$\text{Volume (meters}^3\text{)} = \frac{\text{liters}}{1} \times \frac{1 \text{ meter}^3}{1000 \text{ liters}}$$

$$\text{Volume (meters}^3\text{)} = \frac{90 \text{ liters}}{1} \times \frac{1 \text{ meter}^3}{1000 \text{ liters}}$$

$$\text{Volume (meters}^3\text{)} = 0.09 \text{ m}^3$$

(Source: Note 4 of this QTP)

5. Your sample results have returned from the laboratory, which reported the results as a mass of 18 mg. Using the converted sample volume from Question #4, what are your results in  $mg/m^3$ ?

A:

$$\text{Concentration (mg/m}^3\text{)} = \frac{\text{mass reported (mg)}}{\text{volume (m}^3\text{)}}$$

$$\text{Concentration (mg/m}^3\text{)} = \frac{18 \text{ mg}}{0.09 \text{ m}^3}$$

$$\text{Concentration (mg/m}^3\text{)} = 200 \text{ mg/m}^3$$

(Source: Note 5 of this QTP)

---

**STS Line Item 4.5.2.12: Calculate time-weighted averages\***


---

**TRAINER GUIDANCE**

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	None
<b>Training References:</b>	<ul style="list-style-type: none"> <li>• <i>Fundamentals of Industrial Hygiene</i>, 5th Edition, Chapter 15.</li> <li>• American Conference of Governmental Industrial Hygienist (ACGIH), <i>TLVs® and BEIs®</i> (guidebook), most current edition.</li> </ul>
<b>Additional Supporting References:</b>	<ul style="list-style-type: none"> <li>• 29 CFR 1910.1000(d).</li> <li>• NIOSH Publication No. 77-173, <i>Occupational Exposure Sampling Strategy Manual</i>, Appendix H.</li> </ul>
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>• Air sampling results.</li> <li>• American Conference of Governmental Industrial Hygienist (ACGIH), <i>TLVs® and BEIs®</i> (guidebook), most current edition.</li> <li>• Calculator.</li> </ul>
<b>Specific Techniques:</b>	Conduct hands-on training and evaluation.
<b>Criterion Objective:</b>	Given air sampling results and a calculator, calculate time-weighted averages successfully completing all checklist items with no trainer assistance.
<b>Notes:</b> *The time-weighted average (TWA) exposure evolved as a method to calculate daily or full-shift average exposures, given that individuals' job tasks may vary during a day and that facility operating conditions can also vary. In typical work environments, individuals may experience several different, short-term exposures to the same material. By taking a time-weighted average of these exposures, you can estimate the short-term measurements into an 8-hour exposure estimate and compare this to the applicable standard.	

## TASK STEPS

1. Determine concentration (C) of a given substance based on air sampling results.
2. Determine the collection time in hours (T) for each concentration.
3. Select the appropriate equation.
4. Calculate an 8-hour TWA.<sup>1</sup>
5. Calculate a 15-minute TWA.<sup>2</sup>

### LOCAL REQUIREMENTS:

### NOTES:

1. The time-weighted average is determined by the following formula, where

C = concentration of the contaminant

T = time period during which this concentration was measured

$$8\text{hour TWA} = \frac{C_1 T_1 + C_2 T_2 + C_n T_n}{8 \text{ hours}}$$

2. A 15-minute TWA is typically referred to as a short-term exposure limit (STEL). The STEL is the concentration of the contaminant to which it is believed that workers can be exposed for a short period of time without suffering from 1) irritation, 2) chronic or irreversible tissue damage, 3) dose-rate-dependent toxic effects, or 4) loss of feeling or consciousness. When a chemical has a STEL listed, it cannot be exceeded in a 15-minute period. The 15-minute TWA (STEL) is determined by the following formula, where

C = concentration of the contaminant

T = time period during which this concentration was measured

$$15\text{minute TWA (STEL)} = \frac{C_1 T_1 + C_2 T_2 + C_n T_n}{15 \text{ minutes}}$$

**Note:** Exposures above the 8-hour TWA and below the 15-minute STEL should not be exceeded more than four times in an 8-hour workday, and there should be at least 60-minutes between successive STEL exposures.

---

**TRAINEE REVIEW QUESTIONS**

---

---

**STS Line Item 4.5.2.12: Calculate time-weighted averages**

---

1. You have sampled for methyl ethyl ketone. The results are:

Sample number	Time	Results
1	0800 to 1000	220 ppm
2	1020 to 1220	210 ppm
3	1330 to 1430	110 ppm
4	1500 to 1600	80 ppm

Select the appropriate formula and calculate an 8-hour TWA using the data above:

2. You have sampled for ethylene glycol. The results are:

Sample number	Time	Results
1	0915 to 0920	8.2 mg/m <sup>3</sup>
2	0930 to 0935	7.5 mg/m <sup>3</sup>
3	0945 to 0950	8.0 mg/m <sup>3</sup>

Select the appropriate formula and calculate a 15-minute TWA (STEL) using the following data:

## PERFORMANCE CHECKLIST

### STS Line Item 4.5.2.12: Calculate time-weighted averages

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...	YES	NO
1. Determine concentration (C) of a given substance based on air sampling results?		
2. Determine the collection time in hours (T) for each concentration?		
3. Select appropriate equation?		
4. Calculate an 8-hour TWA?		
5. Calculate a 15-minute TWA?		
<b>Did the trainee successfully complete the task?</b>		

---

 TRAINEE NAME (PRINT)

---

 TRAINER NAME (PRINT)

**ANSWERS**

1. You have sampled for methyl ethyl ketone. The results are:

Sample number	Time	Results
1	0800 to 1000	220 ppm
2	1020 to 1220	210 ppm
3	1330 to 1430	110 ppm
4	1500 to 1600	80 ppm

Select the appropriate formula and calculate an 8-hour TWA using the data above:

A:

$$8\text{hour TWA} = \frac{C_1 T_1 + C_2 T_2 + C_n T_n}{8 \text{ hours}}$$

$$8\text{hour TWA} = \frac{(200 \text{ ppm} \times 2 \text{ hrs}) + (210 \text{ ppm} \times 2 \text{ hrs}) + (110 \text{ ppm} \times 1 \text{ hr}) + (80 \text{ ppm} \times 1 \text{ hr})}{8 \text{ hours}}$$

$$8\text{hour TWA} = \frac{(400 \text{ ppm/hr}) + (420 \text{ ppm/hr}) + (110 \text{ ppm/hr}) + (80 \text{ ppm/hr})}{8 \text{ hours}}$$

$$8\text{hour TWA} = \frac{1050 \text{ ppm/hr}}{8 \text{ hours}}$$

$$8\text{hour TWA} = 131.25 \text{ ppm}$$

Note: Once trainee has completed calculation; have them compare their results to adopted values presented in the American Conference of Governmental Industrial Hygienist (ACGIH), TLVs® and BEIs® (guidebook), most current edition. Trainee should be able to identify if results have exceeded the recommended time weighted-average.

(Source: Note 1 of this QTP and Career Development Course 4B051)

2. You have sampled for ethylene glycol. The results are:

Sample number	Time	Results
1	0915 to 0920	8.2 mg/m <sup>3</sup>
2	0930 to 0935	7.5 mg/m <sup>3</sup>
3	0945 to 0950	8.0 mg/m <sup>3</sup>

Select the appropriate formula and calculate a 15-minute TWA (STEL) using the following data:

A:

$$15\text{minute TWA (STEL)} = \frac{C_1 T_1 + C_2 T_2 + C_n T_n}{15 \text{ minutes}}$$

$$15\text{minute TWA (STEL)} = \frac{(8.2 \text{ mg/m}^3 \times 5 \text{ mins}) + (7.5 \text{ mg/m}^3 \times 5 \text{ mins}) + (8.0 \text{ mg/m}^3 \times 5 \text{ mins})}{15 \text{ minutes}}$$

$$15\text{minute TWA (STEL)} = \frac{(41 \text{ mg/m}^3/\text{min}) + (37.5 \text{ mg/m}^3/\text{min}) + (40 \text{ mg/m}^3/\text{min})}{15 \text{ minutes}}$$

$$15\text{minute TWA (STEL)} = \frac{(118.5 \text{ mg/m}^3/\text{min})}{15 \text{ minutes}}$$

$$15\text{minute TWA (STEL)} = 7.9 \text{ mg/m}^3$$

Note: Once trainee has completed calculation; have them compare their results to adopted values presented in the American Conference of Governmental Industrial Hygienist (ACGIH), TLVs® and BEIs® (guidebook), most current edition. Trainee should be able to identify if results have exceeded the recommended time weighted-average.

(Source: Note 2 of this training module and Career Development Course 4B051)



---

**STS Line Item 4.5.2.13: Calculate upper and lower confidence limits**


---

**TRAINER GUIDANCE**

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	None
<b>Training References:</b>	<ul style="list-style-type: none"> <li>• ACGIH TLV Booklet, 2008</li> <li>• 29 CFR 1910.1000(d)</li> </ul>
<b>Additional Supporting References:</b>	<i>Fundamentals of Industrial Hygiene</i> , 5 <sup>th</sup> edition <a href="http://www.cdc.gov/niosh/docs/2003-154/">http://www.cdc.gov/niosh/docs/2003-154/</a>
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>• Air sampling results</li> <li>• Calculator</li> <li>• <i>NIOSH Manual of Analytical Methods</i></li> <li>• ACGIH TLV Booklet</li> </ul>
<b>Specific Techniques:</b>	Conduct hands-on training and evaluation.
<b>Criterion Objective:</b>	Given air sampling results and references, calculate upper and lower confidence limits successfully completing all checklist items with no trainer assistance.
<b>Notes:</b>	See Notes Section for formulas.

## TASK STEPS

1. Obtain laboratory results of analyte(s) sample
2. Determine the standard concentration of the analyte(s) and the sampling procedure information<sup>1</sup>
3. Identify the sampling and analytical error (SAE) factor for the analyte(s)<sup>2</sup>
4. Calculate the upper confidence limit (UCL)<sup>3</sup>
5. Calculate the lower confidence limit (LCL)<sup>4</sup>
6. Recognize when the OEEL could be exceeded<sup>5</sup>
7. Utilize OEHMIS (DOEHRS or equivalent), as applicable.

### LOCAL REQUIREMENTS:

### NOTES:

1. The standardized concentration of an analyte takes into consideration random fluctuations of its presence throughout the sampling process. This variation is expressed by the National Institute for Occupational Safety and Health (NIOSH) as  $S_{rT}$  which is an equivalent term indicating the measure of precision. It can be found in the *NIOSH Manual of Analytical Methods*. The standardized concentration, therefore, can be expressed by the following formula where Y equals standardized concentration and X equals the full period sampling result obtained in step one:

$$Y = \frac{X}{OEEL}$$

The occupational exposure limit can be found in the ACGIH TLV Booklet. It is expressed as either a time-weighted average (TWA) or as a short-term exposure limit (STEL). The sampling results obtained will determine which value to use based on the sampling procedure.

2. The SAE is expressed by multiplying the precision measurement obtained in the *NIOSH Manual of Analytical Methods* by the statistical constant 1.645. In other words, an SAE is found by the  $S_{rT}$  multiplied by 1.645, e.g., the SAE of methylene chloride is 0.042 ( $S_{rT} = 0.026 \times 1.645$ ).

$$SAE = S_{rT} \times 1.645$$

3. The formula to calculate the upper confidence level (UCL) is the following:

$$UCL = Y + SAE$$

4. The formula to calculate the lower confidence limit (LCL) is as follows:

$$LCL = Y - SAE$$

5. If the TWA is already above the OEEL, there is no need to calculate the UCL; however, an LCL should be calculated. If the SAE results in a UCL of more than 1, it is not clear whether the exposure was in compliance. An error of method could make it unclear as to if the exposure was too high.

- If the  $UCL < 1$ , it is with 95 percent confidence that an overexposure does not exist.
- If the  $LCL < 1$  and the  $UCL > 1$ , it is not certain, so may be classified as a possible overexposure.
- If the  $LCL > 1$ , it is with 95 percent confidence that an overexposure exists.

**TRAINEE REVIEW QUESTIONS**

---

**STS Line Item 4.5.2.13: Calculate upper and lower confidence limits**

---

1. What do calculated UCL and LCL values represent?

2. What is the SAE of methylene chloride?

3. Calculate the UCL and LCL for a continuous sampling for the aromatic hydrocarbon benzene. The laboratory results were 0.46ppm TWA. Did an overexposure occur?

## PERFORMANCE CHECKLIST

### STS Line Item 4.5.2.13: Calculate upper and lower confidence limits

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...	YES	NO
1. Obtain laboratory results of analyte(s) sample?		
2. Determine the standard concentration of the analyte(s) and the sampling procedure information?		
3. Identify the sampling and analytical error (SAE) factor for the analyte(s)?		
4. Calculate the upper confidence limit (UCL)?		
5. Calculate the lower confidence limit (LCL)?		
6. Recognize when the OEEL could be exceeded?		
7. Utilize OEHMIS (DOEHRS or equivalent), as applicable?		
<b>Did the trainee successfully complete the task?</b>		

---

 TRAINEE NAME (PRINT)

---

 TRAINER NAME (PRINT)

## ANSWERS

1. What do calculated UCL and LCL values represent?

A: The UCL and LCL incorporate SAE factors statistically in order to obtain the lowest (LCL) and highest (UCL) value that the true exposure could be, within a 95-percent confidence interval.

(Source: Fundamentals of Industrial Hygiene, 5th edition)

2. What is the SAE of methylene chloride?

A:

The SAE of methylene chloride is 0.042.

$$SAE = S_{rT} \times 1.645$$

$$SAE = 0.026 \times 1.645$$

$$SAE = 0.042$$

(Source: Note #2, NIOSH Manual of Analytical Methods)

3. Calculate the UCL and LCL for a continuous sampling for the aromatic hydrocarbon benzene. The laboratory results were 0.46ppm TWA. Did an overexposure occur?

$$Y = \frac{X}{OEEEL}$$

$$Y = \frac{0.46}{0.5}$$

$$\underline{Y = 0.92}$$

$$SAE = S_{rT} \times 1.645$$

$$SAE = 0.013 \times 1.645$$

$$\underline{SAE = 0.021}$$

$$UCL = 0.92 + 0.021 = \underline{0.941}$$

$$LCL = 0.92 - 0.021 = \underline{0.899}$$

A: An overexposure did not occur.

(Source: Note #1 – 5, NIOSH Manual of Analytical Methods and ACGIH TLV Booklet)

---

**STS Line Item 4.5.2.14: Calculate compliance factors (unity)**


---

**TRAINER GUIDANCE**

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.
<b>Prerequisites:</b>	None
<b>Training References:</b>	<ul style="list-style-type: none"> <li>• ACGIH TLV Booklet, 2008, App E</li> <li>• 29 CFR 1910.1000(d)</li> </ul>
<b>Additional Supporting References:</b>	None
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>• Air sampling results</li> <li>• Calculator</li> <li>• <i>NIOSH Pocket Guide to Chemical Hazards</i></li> <li>• ACGIH TLV Booklet</li> </ul>
<b>Specific Techniques:</b>	Conduct hands-on training and evaluation.
<b>Criterion Objective:</b>	Given air sampling results and a calculator, calculate a compliance factor successfully completing all checklist items with no trainer assistance.
<b>Notes:</b> See Notes section for formulas.	

## TASK STEPS

1. Identify the chemical constituents that have similar toxicological effects on the same target organs
2. Identify calculated TWA result and OEL for each constituent identified in step 1
3. Calculate the compliance factor each TLV type (TWA, STEL, C) that applies<sup>1</sup>
4. Interpret the compliance factor<sup>2</sup>
5. Utilize OEHMIS (DOEHRS or equivalent)

### LOCAL REQUIREMENTS:

### NOTES:

1. Formulas:

$$\text{Compliance Factor}_{TWA} = \frac{C_1}{OEL_1} + \frac{C_2}{OEL_2} + \dots \frac{C_n}{OEL_n}$$

Where a substance with a STEL or Ceiling limit is mixed with a substance with a TLV-TWA but no STEL, comparison of the short-term limit with the applicable excursion limit (five times the TLV-TWA limit) may be appropriate.

$$\text{Compliance Factor}_{STEL} = \frac{TWA_1}{OEL_{1STEL}} + \frac{TWA_2}{OEL_{2STEL}} + \dots \frac{TWA_n}{OEL_{nSTEL}}$$

2. A compliance factor of more than one means the OEEL of the mixture has been exceeded.

A compliance factor of 1 or less than 1 means the OEEL of the mixture has not been exceeded and is in compliance.

---

**TRAINEE REVIEW QUESTIONS**

---

---

**STS Line Item 4.5.2.14: Calculate compliance factors (unity)**

---

1. When must a compliance factor be calculated?

2. Use the NIOSH Pocket Guide to determine which of the following substances have the same target organs.

Substance	TWA	OEEL
Vinyl fluoride	.02 ppm	1 ppm
Methylene chloride	45 ppm	50 ppm
Phenol	4 ppm	5 ppm

3. Using the results from question #2, assume toxicological effects on the target organs is the same and calculate compliance factor(s).



4. Using the results from question #3, interpret what each compliance factor means.

## PERFORMANCE CHECKLIST

### STS Line Item 4.5.2.14: Calculate compliance factors (unity)

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed.

DID THE TRAINEE...	YES	NO
1. Identify the chemical constituents that have similar toxicological effects on the same target organs?		
2. Collect calculated TWA result and OEEL for each constituent identified above?		
3. Calculate the compliance factor each OEEL (TWA, STEL, C) that applies?		
4. Interpret the compliance factor?		
5. Utilize OEHMIS (DOEHRS or equivalent)?		
<b>Did the trainee successfully complete the task?</b>		

---

 TRAINEE NAME (PRINT)

---

 TRAINER NAME (PRINT)

**ANSWERS**

1. When must a compliance factor be calculated?

A: A compliance factor must be calculated when a worker is exposed to two or more chemicals on the same shift that have similar toxicological effects.

(Source: Career Development Course 4B051)

2. Use the NIOSH Pocket Guide to determine which of the following substances have the same target organs.

Substance	TWA	OEEL
Vinyl fluoride	.02 ppm	1 ppm
Methylene chloride	45 ppm	50 ppm
Phenol	4 ppm	5 ppm

A:

Methylene chloride and phenol target the eyes and skin.

Vinyl fluoride and methylene chloride both have central nervous system effects.

(Source: NIOSH Pocket Guide to Chemical Hazards)

3. Using the results from question #2, assume toxicological effects on the target organs is the same and calculate compliance factor(s).

A:

Two separate calculations are needed:

1: Methylene chloride and phenol (eyes and skin)

$$\text{Compliance Factor}_{TWA} = \frac{45}{50} + \frac{4}{5}$$

$$\text{Compliance Factor}_{TWA} = 0.9 + 0.8$$

$$\text{Compliance Factor}_{TWA} = 1.7$$

2: Vinyl fluoride and methylene chloride (central nervous system)

$$\text{Compliance Factor}_{TWA} = \frac{0.02}{1} + \frac{45}{50}$$

$$\text{Compliance Factor}_{TWA} = 0.02 + 0.9$$

$$\text{Compliance Factor}_{TWA} = 0.902$$

(Source: Career Development Course 4B051, and NIOSH Pocket Guide to Chemical Hazards)

4. Using the results from question #3, interpret what each compliance factor means.

1: Methylene chloride and phenol (eyes and skin)

$$\text{Compliance Factor}_{TWA} = 1.7$$

A: A compliance factor of more than one means the OEEL of the mixture has been exceeded.

2: Vinyl fluoride and methylene chloride (central nervous system)

$$\text{Compliance Factor}_{TWA} = 0.902$$

A: A compliance factor of 1 or less than 1 means the OEEL of the mixture has not been exceeded and is in compliance.

(Source: Note 2 and Career Development Course 4B051)

## STS Line Item 4.5.2.16: Interpret air sample results

### TRAINER GUIDANCE

<b>Proficiency Code:</b>	2b
<b>PC Definition:</b>	Can do most parts of the task. Needs help only on hardest parts. Can determine step-by-step procedures for doing the task.
<b>Prerequisites:</b>	None
<b>Training References:</b>	<p>ESOH Service Center, Laboratory Sampling Guide  <a href="https://hpws.afrl.af.mil/dhp/OE/ESOHSC/pages/index.cfm?id=742">https://hpws.afrl.af.mil/dhp/OE/ESOHSC/pages/index.cfm?id=742</a>            AFMAN 48-146, <i>Occupational and Environmental Health Program Management</i>. 9 October 2012.            NIOSH Pocket Guide to Chemical Hazards <a href="http://www.cdc.gov/niosh/npg/">http://www.cdc.gov/niosh/npg/</a> (or equivalent chemical reference)            AFMAN 48-155, <i>Occupational and Environmental Health Program</i>            Latest edition of the TLV® Booklet from the American Conference of Governmental Industrial Hygienists (ACGIH)</p>
<b>Additional Supporting References:</b>	AFI48-145, <i>Occupational and Environmental Health Program</i> , 15 September 2011
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	<ul style="list-style-type: none"> <li>• Sample Report</li> <li>• Calculator</li> </ul>
<b>Specific Techniques:</b>	Conduct 4.5.2.16 - Interpret Air Sample Results in conjunction with 4.5.2.12 - Calculate Time-weighted Averages and 4.5.2.13 - Calculate Upper and Lower Confidence Limits.
<b>Criterion Objective:</b>	Given a Laboratory Sample Report of air sampling results, interpret the data to identify discrepancies successfully completing all steps with limited trainer assistance.
<b>Notes:</b> Trainee should be able to read a Laboratory Sample Report, and identify discrepancies, sample results, blanks, and be able to perform blank corrections. Know how to compare the final Time-weighted Average (TWA) results to the Occupational Environmental Exposure Limit (OEEL).	

**TASK STEPS**

1. Locate "Narrative Comments" on sample report.
2. Identify if data is valid.
3. Check for any comments that might affect your samples.
4. Review sample information for correctness. (Sample ID, Air Volume, Date Sampled, Analyte, Method Reference – ensure these match what you had sent in.)
5. Check for qualifiers.
6. Check dilution factors.
7. Identify sample(s).
8. Identify blank(s).
9. Check if contaminant is detected greater than the Reporting Limit (RL) on media blanks.
10. Determine if blank correction is necessary.
11. Perform blank correction (if necessary) IAW Laboratory Sampling Guide for all samples.
12. Calculate TWA IAW QTP 4.5.2.12.
13. Calculate upper and lower confidence limits IAW QTP 4.5.2.13.
14. Compare resulting TWA to OEEL and determine if limit was exceeded.

**LOCAL REQUIREMENTS:****NOTES:**

**TRAINEE REVIEW QUESTIONS**

---

**STS Line Item 4.5.2.16: Interpret air sample results**

---

1. Where would you look to find any discrepancies or potential issues with your sample results?

2. What must be done with the sample result before it can be compared to the OEEL?

## PERFORMANCE CHECKLIST

### STS Line Item 4.5.2.16: Interpret air sample results

<b>Proficiency Code:</b>	2b
<b>PC Definition:</b>	Can do most parts of the task. Needs help only on hardest parts. Can determine step by step procedures for doing the task.

DID THE TRAINEE...		YES	NO
1. Locate "Narrative Comments" on sample report?			
2. Identify if data is valid?			
3. Check for any comments that might affect your samples?			
4. Review sample information for correctness. (Sample ID, Air Volume, Date Sampled, Analyte, Method Reference – ensure these match what you had sent in.)?			
5. Check for qualifiers?			
6. Check dilution factors?			
7. Identify sample(s)?			
8. Identify blank(s)?			
9. Check if contaminant is detected greater than the reporting limit (RL) on media blanks?			
10. Determine if blank correction is necessary?			
11. Perform blank correction (if necessary) IAW Laboratory Sampling Guide for all samples?			
12. Calculate TWA IAW QTP 4.5.2.12?			
13. Calculate upper and lower confidence limits IAW QTP 4.5.2.13?			
14. Compare resulting TWA to OEEL and determine if limit was exceeded?			
<b>Did the trainee successfully complete the task?</b>			

TRAINEE NAME (PRINT)

TRAINER NAME (PRINT)



## **ANSWERS**

1. Where would you look to find any discrepancies or potential issues with your sample results?

A: You would check for any comments in the Narrative Comments.

(Source: Laboratory Sampling Guide, Page 9, Section 1.17.3)

2. What must be done with the sample result before it can be compared to the OEEL?

A: Your sample result must be in the same units as your OEEL in order to be able to compare them.

(Source: Career Development Course 4B051)

---

**STS Line Item 4.5.2.17: DOEHRS data entry**


---

**TRAINER GUIDANCE**

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed
<b>Prerequisites:</b>	None
<b>Training References:</b>	DOEHRS student guides <a href="https://doehrs-ih.csd.disa.mil/doehrs/displaystudentsguides.do">https://doehrs-ih.csd.disa.mil/doehrs/displaystudentsguides.do</a>
<b>Additional Supporting References:</b>	
<b>CDC Reference:</b>	4B051
<b>Training Support Material:</b>	None
<b>Specific Techniques:</b>	Have trainee enter information into DOEHRS IAW DOEHRS student guides
<b>Criterion Objective:</b>	Given a source of data (case file, sampling event, observations, etc.), input data into DOEHRS system IAW DOEHRS student guides and applicable local policy successfully completing all steps with NO trainer assistance.
<b>Notes:</b> Trainee must be given information from case files to enter into DOEHRS	

**TASK STEPS**

1. Determine type of data.<sup>1</sup>
2. Enter correct module of DOEHRS.
3. Input data.<sup>2</sup>
4. Verify accuracy of data.

**LOCAL REQUIREMENTS:****NOTES:**

1. Data may be any one of the following types:
  - Observations and notes or shop data
  - Environmental survey
  - Radiation survey
  - Incident response
  - SEG survey
2. Be sure to fill out all mandatory forms IAW applicable DOEHRS student guides and local policy.

**TRAINEE REVIEW QUESTIONS**

---

**STS Line Item 4.5.2.17: DOEHS data entry**

---

1. What is the AF-approved OEH Management Information System called?

2. What are the four modules of DOEHS?

3. What must be documented in DOEHS?

## PERFORMANCE CHECKLIST

### STS Line Item 4.5.2.17: DOEHRS data entry

<b>Proficiency Code:</b>	3c
<b>PC Definition:</b>	Can do all parts of the task. Needs only a spot check of completed work. Can identify why and when the task must be done and why each step is needed

DID THE TRAINEE...		YES	NO
1. Determine type of data?			
2. Enter correct module of DOEHRS?			
3. Input data?			
4. Verify accuracy of data?			
<b>Did the trainee successfully complete the task?</b>			

---

 TRAINEE NAME (PRINT)

---

 TRAINER NAME (PRINT)

## **ANSWERS**

1. What is the AF-approved OEH Management Information System called?

A: Defense Occupational and Environmental Health Readiness System (DOEHRS).

(Source: Career Development Course 4B051)

2. What are the four modules of DOEHRS?

A: Industrial Hygiene, Environmental Health, Radiation, Incident Reporting

(Source: Career Development Course 4B051)

3. What must be documented in DOEHRS?

All information relating to OEH health risk assessment

(Source: Career Development Course 4B051)